

HT21

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

GPL®



⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

KEY NO.	PART NO.	DESCRIPTION
1	530 01 58-10	Screw-Shroud
2	530 03 80-13	Shroud
3	530 02 99-29	Crankcase Cover
4	530 01 91-81	Gasket-Shrd./C'case
5	530 01 43-07	Crankshaft Ass'y.
6	530 03 21-25	Inner Bearing
7	530 01 59-45	Retainer-C'case
8	530 01 91-79	Crankcase Seal
9	530 03 21-24	Outer Bearing
10	530 01 48-61	Crankcase Ass'y. (Incl. 6-9)
11	530 01 59-41	Retaining Ring
12	530 01 60-80	Screw-Pulley
13	530 03 91-49	Flywheel Ass'y.
14	530 03 61-45	Spacer-Ignition Module
15	530 03 91-63	Ignition Module
16	530 01 59-54	Screw-Ignition Module
17	530 03 77-30	Spring-Starter Dog
18	530 02 99-39	Starter Dog
19	530 01 58-28	Washer
20	530 01 59-30	Flywheel Spacer
21	530 06 92-32	Rope Kit
22	530 01 59-63	Retainer
23	530 01 54-96	Screw-Retainer
24	530 06 93-53	Starter Pulley
25	530 02 93-95	Starter Spring
26	530 02 75-69	Starter Handle
27	530 01 58-86	Screw-Fan Housing
28	530 01 43-96	Clutch Ass'y. Kit
29	530 01 46-10	Fan Housing
30	530 01 91-82	Grommet



KEY NO.	PART NO.	DESCRIPTION
31	530 01 58-82	Screw-Flywheel
32	530 02 99-30	Muffler Spring
33	530 02 38-77	Fuel Line Fitting
34	530 03 61-80	Muffler Screen
35	530 01 59-34	Screw-Fan Hsg/Shrd.
36	530 06 93-52	Muffler Kit
37	530 01 92-23	Cylinder Gasket
38	530 02 99-24	Piston Ring
39	530 06 96-13	Piston Kit (Incl. 38 & 55)
40	530 01 59-53	Screw-Cylinder
41	530 06 46-14	Cylinder
42	503 23 50-08	Spark Plug (CJ-8Y)
43	530 01 91-85	Gasket-Cylinder/Carburetor
44	530 03 80-17	Carburetor Adaptor
45	530 01 60-14	Screw-Carburetor Adaptor
46	530 01 43-84	Throttle Cable Ass'y.
47	530 01 57-75	Screw-Throttle Cable
48	530 01 91-94	Gasket-Carburetor Adaptor
49	530 03 61-92	Air Box
50	530 03 53-06	Carburetor
51	530 01 58-49	Screw-Air Box
52	530 02 99-34	Air Filter Foam
53	530 03 61-93	Air Filter Cover
54	530 01 56-35	Screw-A.F. Cover
55	530 01 51-62	Piston Pin Retainer
58	530 06 95-99	Fuel Line Kit (Incl. Fuel and Vent Lines)
59	530 01 61-03	Retainer Clip
60	530 01 43-62	Fuel Pick-up Ass'y.
61	530 06 96-15	Connecting Rod Kit

Type 1 - Carburetor Number

#530-035306-WT-221

Type 2 - Carburetor Number

#530-069682-WT-379 only for USA

KEY PART
NO. NO.

DESCRIPTION

1	530 02 99-54	Ignition Switch
2	530 03 64-43	Lead Wire Ass'y.
3	530 01 57-75	Screw-Handle Cover
4	530 02 99-58	Trigger Lever
5	530 01 59-40	Screw-Handle Cover
6	530 01 57-70	Screw-Handle Cover
7	530 03 83-05	Handle Cover
8	530 02 99-56	Throttle Trigger
9	530 03 61-22	Throttle Lockout
10	530 03 61-23	Trigger Spring
11	530 01 59-34	Screw-Handle Cover
12	530 04 71-96	Rear Handle/Tank Ass'y.
13	530 09 49-92	Front Handle
14	530 02 99-46	Isolator Spring
15	530 04 81-13	Clutch Drum
16	530 01 58-14	Screw
17	530 02 99-16	Gear Box Plate
18	530 03 21-21	Bushing Blade
19	530 03 63-71	Blade Assty.
20	530 02 99-48	BladeSeal
21	530 03 62-28	Pinion Ass'y.
22	530 01 60-13	Drive Gear Bearings
23	530 06 93-55	Drive Gear Kit
24	530 03 60-46	Isolator Plate
25	530 01 48-71	Fuel Cap Ass'y.
26	530 01 59-55	Screw-Front Handle
27	530 01 58-86	Screw-Gear
28	530 01 43-99	Gear Box Ass'y. (Incl. 21, 22 & 27)

KEY PART
NO. NO.

DESCRIPTION

Type 1 only		
29	530 03 50-14	Metering Diaphragm
30	530 03 53-20	Metering Diaphragm Gasket
31	530 03 50-16	Pump Gasket
32	530 03 50-17	Pump Diaphragm
33	530 03 52-50	Metering Pin
34	530 03 50-31	Metering Lever
35	530 03 51-78	Fuel Inlet Screen
36	530 03 52-23	Inlet Needle Valve
37	530 03 51-39	Metering Lever Spring
38	530 03 52-36	Metering Lever Pin Screw
39	530 03 53-19	Welch Plug
40	530 03 52-13	Gasket/Diaphragm Kit (Incl. 29-32)
41	530 03 53-12	Carb. Repair Kit (Incl. 33-38 & 40)
41	530 06 96-56	Type 2 (• Indicates Contents)
Type 2 Only for USA		
42	530 06 97-11	Primer Repair Kit (* Indicates Contents)
43	530 03 83-17	Limiter Cap-Low
44	530 03 83-18	Limiter Cap-High