

HT 2130

Spare parts

Ersatzteile




Pièces détachées

Reserve onderdelen


Repuestos

Reservdelar

GPL®

A***compl 531 00 49-51****B****D**


E




Exploded view diagram of a generator assembly. The diagram shows the following components and their part numbers:

- 501 36 44-19
- 531 00 49-39
- 501 36 44-21
- 531 00 49-78
- 531 00 49-43
- 501 36 48-12 (x2)
- 501 36 44-23 (x2)
- 501 36 44-24
- 531 00 49-41
- 735 11 46-01 (x2)
- 531 00 49-44
- 725 53 43-55 (x2)
- 501 36 51-46
- 501 36 22-30
- 501 36 44-25
- 501 36 55-11
- 531 00 49-45


H




J





K



L



M***compl 531 00 49-78****WYL 120****N**

MODEL 2130

PART NUMBER	SQUARE NOTE	PART NUMBER	SQUARE NOTE	PART NUMBER	SQUARE NOTE	PART NUMBER	SQUARE NOTE
501 36 02-05	J	501 36 48-83	J	531 00 72-61	G N		
501 36 10-21	K	501 36 48-84	B	531 00 72-66	D N		
501 36 11-88	J	501 36 48-86	D	725 52 87-55	A		
501 36 11-94	J	501 36 49-16	D	725 53 27-55	L		
501 36 15-03	E	501 36 49-19	K	725 53 37-55	L		
501 36 17-69	D	501 36 49-33	K	725 53 41-55	A		
501 36 18-52	E	501 36 49-38	J	725 53 43-55	G		
501 36 20-08	E	501 36 51-46	G	732 25 12-01	L		
501 36 20-14	E	501 36 53-80	F	735 11 46-01	G		
501 36 20-32	F	501 36 54-13	H	735 11 53-01	K		
501 36 21-41	L	501 36 54-27	M	735 11 53-50	J		
501 36 21-60	L	501 36 55-11	G	735 31 17-00	K		
501 36 21-61	L	501 36 72-06	H				
501 36 21-63	L	501 36 72-38	H				
501 36 22-30	G	501 36 72-39	H				
501 36 23-75	L	501 36 72-40	H				
501 36 23-78	N	503 22 24-02	K N				
501 36 23-79	N	503 23 00-11	A				
501 36 24-22	M	503 23 50-11	B				
501 36 24-50	L	503 89 67-01	M N				
501 36 30-12	D	505 31 67-54	M				
501 36 31-15	H	531 00 24-21	M				
501 36 31-40	K	531 00 49-01	B				
501 36 33-61	M	531 00 49-26	E N				
501 36 37-54	M	531 00 49-27	E N				
501 36 37-65	M	531 00 49-28	E N				
501 36 37-66	M	531 00 49-29	E N				
501 36 37-70	M	531 00 49-30	E N				
501 36 39-17	L	531 00 49-31	E N				
501 36 39-52	L	531 00 49-32	E N				
501 36 39-53	L	531 00 49-33	B N				
501 36 44-00	B	531 00 49-34	B N				
501 36 44-02	E	531 00 49-35	B N				
501 36 44-04	E	531 00 49-38	D N				
501 36 44-06	E	531 00 49-39	G N				
501 36 44-07	E	531 00 49-40	D N				
501 36 44-09	B	531 00 49-41	G N				
501 36 44-12	A	531 00 49-42	D N				
501 36 44-16	H	531 00 49-43	G N				
501 36 44-17	A	531 00 49-44	G N				
501 36 44-19	G	531 00 49-45	G N				
501 36 44-21	G	531 00 49-46	H N				
501 36 44-23	G	531 00 49-47	H N				
501 36 44-24	G	531 00 49-48	H N				
501 36 44-25	G	531 00 49-49	F N				
501 36 44-27	K	531 00 49-50	A N				
501 36 44-30	F	531 00 49-51	A N				
501 36 44-32	H	531 00 49-53	A N				
501 36 44-34	M	531 00 49-56	K N				
501 36 44-38	K	531 00 49-57	K N				
501 36 44-40	K	531 00 49-58	KL N				
501 36 44-41	K	531 00 49-60	K N				
501 36 44-44	K	531 00 49-66	J N				
501 36 44-45	K	531 00 49-67	J N				
501 36 44-49	K	531 00 49-68	J N				
501 36 44-51	K	531 00 49-69	J N				
501 36 48-06	B	531 00 49-70	J N				
501 36 48-12	G	531 00 49-71	J N				
501 36 48-18	L	531 00 49-72	K N				
501 36 48-19	L	531 00 49-73	J N				
501 36 48-22	L	531 00 49-74	L N				
501 36 48-24	L	531 00 49-75	L N				
501 36 48-25	L	531 00 49-76	L N				
501 36 48-26	L	531 00 49-77	L N				
501 36 48-27	L	531 00 49-78	GM N				
501 36 48-72	L	531 00 49-79	M N				
501 36 48-73	L	531 00 49-80	M N				
501 36 48-77	D	531 00 49-81	M N				
501 36 48-78	J	531 00 49-82	H N				
501 36 48-82	N	531 00 49-83	H N				

N = New part
 Neues teil
 Nouvelle piece
 Nueva pieza
 Ny detalj