

CS2240, CS2240 S

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar

GPL®


A1 CS2240S



Page A1 CS2240S

Position	Article	Quantity	Description	Kit
1	544 19 49-02	1	Clutch cover assy	
2	504 54 28-01	1	Cover	1
3	544 30 60-01	1	Brake band assy	1
4	544 25 31-01	1	Wear protection	1
5	503 85 52-01	1	Guide bushing	1
6	503 89 26-01	1	Brake spring	1
7	544 24 85-01	1	Cover lid	1
8	503 89 08-02	1	Knee joint	1
9	503 89 29-01	1	Pin knee joint	1
10	735 31 08-20	1	E-clip	1
11	537 39 29-01	1	Chain tension screw	1
12	537 34 72-02	1	Chain tensioner wheel	1
13	537 39 26-02	1	Heat protector	1
14	544 35 75-02	1	Label	1
15	503 21 70-10	10	Screw	1
16	544 84 55-01	1	Bearing sleeve	1
17	544 25 05-01	1	Wear plate	1
18	537 34 78-02	1	Knob	






Position	Article	Quantity	Description	Kit
1	501 38 82-02	1	Clutch cover assy	
2	735 31 08-20	1	E-clip	1
3	537 28 66-01	1	Pawl	1
4	540 06 33-01	1	Chain guide	1
5	537 01 74-01	1	Bearing sleeve	1
6	503 89 08-02	1	Knee joint	1
7	505 89 26-01	1	Brake spring	1
8	503 85 52-01	1	Guide bushing	1
9	544 24 85-01	1	Cover lid	1
10	503 21 70-10	7	Screw	1
11	544 25 31-01	1	Wear protection	1
12	544 30 60-01	1	Brake band assy	1
13	503 89 29-01	1	Pin	1
14	537 39 70-01	1	Worm screw	1
15	537 07 94-02	1	Worm wheel	1
16	740 48 07-02	1	O-ring	1
17	503 23 00-63	1	Washer	1
18	544 37 68-02	1	Label, clutch cover	1
19	503 22 00-01	1	Nut	




B

CS2240, CS2240S



Position	Article	Quantity	Description	Kit
1	544 87 12-01	1	Clutch assy	
2	502 08 03-01	2	Clutch spring	1
3	505 44 15-01	1	Clutch drum assy	
4	503 53 92-01	1	Support bushing	3
5	544 21 24-01	1	Worm gear	
6	540 05 79-01	1	Pump piston	
7	537 15 48-01	1	Pump cylinder	
8	544 08 42-01	1	Oil hose	






Page C **CS2240**
CS2240S



Position	Article	Quantity	Description	Kit
1	505 19 21-01	1	Cylinder cover kpl	
2	503 89 47-02	1	Snap	

GPL®

D1 CS2240



1




Page D1 CS2240S

Position	Article	Quantity	Description	Kit
1	516 02 07-02	1	Starter assy, std	
2	505 42 54-01	1	Starter housing	1
3	510 41 11-01	1	Reinforcement sleeve	1
4	540 05 75-01	1	Spring cassette assy	1
5	503 21 28-10	2	Screw CCRPANT	1
6	537 42 32-01	1	Starter pulley	1
7	537 42 66-01	1	Screw IHSCT	1
8	505 30 51-25	1	Starter cord	1
9	544 37 65-01	1	Starter handle	1
10	503 21 73-21	4	Screw CIHSCTO	1
11	510 44 33-01	1	Driver	1
12	544 19 71-01	1	Cooling air conductor	
13	522 59 98-01	1	Label, Starter	




D2 CS2240S



Page D2 CS2240S


Position	Article	Quantity	Description	Kit
1	505 42 55-02	1		
2	505 42 54-01	1	Starter housing	1
3	510 41 11-01	1	Reinforcement sleeve	1
4	540 05 75-01	1	Spring cassette assy	1
5	503 21 28-10	2	Screw CCRPANT	1
6	537 42 32-01	1	Starter pulley	1
7	505 64 73-01	1	Spring	1
8	537 42 33-01	1	Driver	1
9	537 42 66-01	1	Screw	1
10	505 30 51-25	1	Starter cord	1
11	544 37 65-01	1	Starthandtag	1
12	503 21 73-21	4	Screw CIHSCTO	1
13	522 59 98-02	1	Label, Starter	
14	544 19 71-01	1	Cooling air conductor	






Position	Article	Quantity	Description	Kit
1	544 87 42-01	1	Flywheel assy	
2	537 24 56-01	2	Starter pawl	1
3	501 81 99-03	2	Screw	1
4	503 23 00-42	2	Washer steel	1
5	503 78 32-01	2	Spring	1
6	503 22 04-01	1	Nut	
7	505 42 72-01	1	Ignition module	
8	544 84 82-01	1	Wiring assy	
9	503 20 02-20	2	Screw IHSCFM	






Position	Article	Quantity	Description	Kit
1	544 14 77-01	1	Muffler assy	
2	544 14 84-01	1	Spark arrester	1
3	501 32 31-01	1	Heat deflector	
4	544 08 44-01	1	Gasket	
5	725 53 68-55	2	Screw	





Position	Article	Quantity	Description	Kit
1	504 72 47-01	1	Insulation wall assy	
2	504 72 45-01	1	Insulation wall rubber	1
3	504 72 44-01	1	Insulation wall plastic	1
4	504 20 12-01	1	Inlet pipe	
5	503 20 02-16	4	Screw	
6	506 45 05-01	1	Carburettor	
7	544 28 44-01	1	Throttle rod assy	
8	544 97 64-01	1	Filter holder assy	
9	544 39 26-01	1	Shackle	8
10	504 71 25-01	1	Guide sliding shoe	
11	544 84 43-02	1	Control assy	
12	544 97 66-01	1	Screw	11
13	503 20 02-40	3	Screw	
14	544 80 54-02	1	Air filter assy (44 micron)	
14	544 80 54-03	1	Air filter assy (felt)	
15	503 93 66-01	1	Air purge	
16	544 40 19-01	1	Hose, airpurge suction	






Position	Article	Quantity	Description	Kit
1	504 73 51-01	1	Cylinder assy	
2	502 62 50-02	1	Piston assy	1
3	544 40 59-01	1	Piston ring	2
4	544 40 60-01	1	Piston pin	2
5	537 39 99-01	2	Circlip	2
6	503 41 41-01	1	Needle bearing	1
7	544 39 60-01	1	Gasket, cylinder rear	
8	544 39 59-01	1	Gasket, cylinder front	
9	725 53 33-55	4	Screw	
10	503 23 51-11	1	Spark plug	



J

CS2240, CS2240S




Position	Article	Quantity	Description	Kit
1	544 34 38-01	1	Crankshaft	
2	544 24 87-01	1	Ball bearing 6001 OD32	1
3	544 25 12-01	1	Sealing 12x32x3,7	1
4	544 24 88-01	1	Ball bearing 6001 OD32w	1
5	544 25 13-01	1	Sealing 16,6x32,3,7	1
6	503 41 41-01	1	Needle bearing	



K

CS2240, CS2240S




**Page K CS2240
CS2240S**

Position	Article	Quantity	Description	Kit
1	544 93 25-02	1	Crankcase assy	
2	503 87 58-02	1	Stiffening plate	
3	503 87 54-02	1	Bar bolt	
4	537 33 46-01	1	Bar bolt	
5	544 03 64-01	1	Bar bolt	
6	503 24 09-05	1	Needle roller	
7	530 02 61-19	1	Check valve	
8	537 40 35-01	1	Filter	
9	544 08 33-01	1	Oil screen	
10	544 33 16-01	3	Guide pin	
11	503 86 93-01	1	Support	
12	544 11 12-02	1	Tank cap assy	
13	537 21 50-01	1	Sealing	12
14	503 57 89-01	1	Holder	12
15	503 88 63-01	1	Chain catcher pin	
16	544 31 62-01	2	Screw	
17	501 00 76-01	1	Lateral support	
18	503 21 51-03	1	Screw	
19	544 28 46-01	1	Chain guide plate	
20	503 21 70-10	1	Screw	
21	544 28 65-01	1	Spike inner	
22	503 21 75-20	2	Screw	
23	506 49 25-01	1	Hand guard	
24	503 89 24-01	1	Catch	
25	503 89 30-02	2	Screw	
26	503 43 65-01	1	Lock spring	

L


CS2240, CS2240S



14

Position	Article	Quantity	Description	Kit
1	544 19 38-02	1	Fuel tank assy	
2	503 21 28-10	1	Screw	
3	720 18 25-20	1	Pin	
4	544 96 85-02	1	Throttle control	
5	544 09 99-01	1	Spring	
6	544 28 41-02	1	Throttle lockout	
7	544 28 49-02	1	Handle insert	
8	544 12 86-01	1	Fuel hose	
9	503 44 32-01	1	Filter mix	
10	544 12 97-01	1	Return hose	
11	544 11 12-02	1	Tank cap assy	
12	537 21 50-01	1	Sealing	11
13	503 57 89-01	1	Holder	11
14	544 37 50-01	1	Decal warning	
15	501 00 76-01	1	Lateral support	
16	504 79 56-01	2	Antivibration element	
17	721 12 63-39	1	Grooved pin	
18	537 35 95-01	1	Fuel tank vent	





Page M **CS2240**
CS2240S


Position	Article	Quantity	Description	Kit
1	506 49 26-01	1	Front handle	
2	503 21 88-76	3	Screw	
3	503 89 83-01	1	Antivibration element	

GPL®

N


CS2240, CS2240S

ZAMA C1T-EL41



Position	Article	Quantity	Description	Kit
1	506 45 05-01	1	Zama C1T-EL41	
2	503 48 11-01	1	Piece	1
3	504 02 40-01	1	Nozzle assy	1
4	503 53 56-01	1	Plug welch	1
5	503 47 97-01	1	Valve	1
6	537 02 03-01	1	Spring	1
7	503 66 59-01	1	Lever	1
8	503 48 00-01	1	Pin retaning screw	1
9	504 02 41-01	1	Screw	1
10	505 53 52-01	1	Cap	1
11	504 02 61-01	1	Shaft assy	1
12	505 11 07-01	1	Collar	1
13	504 02 85-01	1	Spring	1
14	504 02 75-01	1	Valve	1
15	503 48 18-01	2	Screw	1
16	504 02 67-01	2	Circlip	1
17	504 02 62-01	1	Shaft assy	1
18	540 05 37-01	1	Lever	1
19	504 02 83-01	1	Spring	1
20	504 02 63-01	1	Lever	1
21	503 47 90-01	2	Screw	1
22	504 02 74-01	1	Valve	1
23	503 48 18-01	2	Screw	1
24	504 02 60-01	1	Shaft assy	1
25	504 02 84-01	1	Spring	1
26	544 98 31-01	1	Lever	1
27	503 47 90-01	2	Screw	1
28	504 02 76-01	1	Valve	1
29	503 47 92-01	1	Screw	1
30	504 02 73-01	1	Screw	1
31	504 90 92-01	1	Screw	1
32	504 02 81-01	1	Screw	1
33	504 02 43-01	1	Gasket	1
34	504 02 45-01	1	Diaphragm	1
35	504 02 46-01	1	Body	1
36	504 02 82-01	1	Screw	1
37	504 02 50-01	1	Strainer	1
38	504 02 56-01	1	Diaphragm	1
39	504 02 57-01	1	Gasket	1
40	504 02 59-01	1	Cover	1
41	504 02 78-01	4	Screw	1
42	504 02 86-01	1	Gasket kit	1

P Levereras endast som reservdel
Delivery as spare part only
Nur als Ersatzteil lieferbar
Livrabable seulement comme pièce de rechange
Solo como repuesto
Zasilà se jenom jako náhradní díl




Page P **CS2240**
CS2240S

Position	Article	Quantity	Description	Kit
1	5047940-01		A	
2	544 39 59-01	1	Gasket, cylinder	
3	544 39 60-01	1	Gasket, cylinder	
4	544 08 44-01	1	Gasket	

GPL®

Q Tillbehör
Accessories
Zubehöre
Accessoires
Accesorios




GPL®

Page Q **CS2240**
CS2240S

Position	Article	Quantity	Description	Kit
1	503 55 85-04	1	Tool	

GPL®

R CS2240, CS2240S
WINTER KIT



Position	Article	Quantity	Description	Kit
1	522 85 72-01	1	Winter kit	
2	503 21 27-13	2	Screw	1
3	503 40 59-01	1	Winter plug	1

