





SPARE PARTS LIST

TRIMMERS/EDGERS

122 LDx


N 122LDx
ACCESSORIES

ACCESSORIES

122 LDx

Ref	Part No	Description	Remark	QTY	KIT
1	545 03 09-01	COMBI GUARD		1	
2	574 52 34-01	KNIFE		1	1
3	530 01 58-14	SCREW		2	1
4	575 73 82-01	COMBINATION WRENCH		1	

A 122LDx
BEVEL GEAR




BEVEL GEAR

122 LDx

Ref	Part No	Description	Remark	QTY KIT	
1	530 09 62-95	BEVEL GEAR		1	
2	537 23 49-01	DRIVER ASSY		1	
3	530 01 60-14	SCREW		1	
4	575 72 57-01	BRACKET		1	
5	522 75 19-01	SCREW ITXSCFM		1	4
6	577 74 59-01	SCREW ITXSCT		1	4


G 122LDx
CARBURETOR & AIRFILTER



CARBURETOR & AIR FILTER

122 LDx

Ref	Part No	Description	Remark	QTY KIT
1	576 88 73-01	FILTER HOLDER ASSY		1
2	524 85 37-01	CHOKE BUTTON		1
3	574 24 27-01	AIR FILTER		1
4	524 85 38-01	FILTER COVER		1
5	537 21 32-09	KNOB		1
6	573 92 58-01	SCREW ITXSCFT		1
7	573 92 58-02	SCREW ITXSCFT		2
8	581 73 43-01	CARBURETTOR		1
9	522 91 12-01	INSULATION WALL		1
10	522 91 85-01	GASKET		1
11	525 76 09-04	SCREW ITXSCM		4
12	525 54 85-01	GASKET		1
13	588 98 60-01	KIT		1


E 122LDx
CLUTCH

CLUTCH

122 LDx

Ref	Part No	Description	Remark	QTY	KIT
1	574 79 42-01	CLUTCH COVER ASSY		1	
2	525 59 37-01	CLUTCH DRUM ASSY		1	1
3	735 31 12-00	CIRCLIP		1	1
4	731 23 14-01	HEXAGON NUT		1	1
5	525 75 51-04	SCREW ITXSCFM		1	
6	525 75 51-01	SCREW ITXSCFM		3	
7	575 38 04-01	DECAL		1	
8	537 03 22-01	CLUTCH ASSY		1	
9	503 81 60-01	CLUTCH SPRING		1	8
10	537 04 68-02	WASHER		1	
11	537 04 67-02	WASHER		1	
12	503 84 29-02	SCREW		2	


M 122LDx
CRANKCASE



CRANKCASE

122 LDx

Ref	Part No	Description	Remark	QTY	KIT
1	522 87 83-01	CRANKCASE ASSY		1	
2	522 87 84-01	PIN		2	1
3	522 91 83-01	GASKET		1	
4	735 31 28-10	CIRCLIP		1	
5	525 75 51-03	SCREW ITXSCFM		3	
6	738 21 01-10	BALL BEARING		2	
7	503 26 02-02	SEALING RING		1	
8	574 48 20-01	RADIAL SEAL		1	


L 122LDx
CRANK SHAFT

CRANKSHAFT

122 LDx

Ref	Part No	Description	Remark	QTY KIT	
1	577 38 05-01	CRANKSHAFT		1	
2	575 50 49-01	NEEDLE BEARING		1	1
3	738 21 01-10	BALL BEARING		2	1
4	503 26 02-02	SEALING RING		1	1
5	574 48 20-01	RADIAL SEAL		1	1


K 122LDx
CYLINDER & PISTON



CYLINDER PISTON

122 LDx

Ref	Part No	Description	Remark	QTY KIT	
1	577 38 03-01	CYLINDER			
2	510 22 36-02	PISTON ASSY		1	1
3	505 15 58-01	PISTON RING		1	1,2
4	737 44 08-00	CIRCLIP		2	1,2
5	525 57 77-01	WASHER		2	1,2
6	575 50 49-01	NEEDLE BEARING		1	1,2
7	525 75 51-02	SCREW ITXSCFM		2	
8	522 91 84-01	GASKET		1	
9	522 99 74-01	AIR CONDUCTOR		1	


D 122LD
FUEL TANK

FUEL TANK

122 LDx

Ref	Part No	Description	Remark	QTY KIT	
1	577 04 48-01	FUEL TANK		1	
2	574 26 30-01	GROMMET		1	1
3	574 60 39-01	FUEL FILTER		1	1
4	574 60 02-02	HOSE	150mm	1	1
5	574 60 01-01	HOSE	155mm	1	1
6	578 97 56-03	FUEL HOSE	225mm	1	1
7	575 48 44-01	VALVE HOUSING		1	1
8	575 48 45-01	VALVE NIPPLE		1	1
9	575 48 46-01	FILTER		1	
10	525 75 51-01	SCREW ITXSCFM		4	
11	544 88 97-01	TANK CAP		1	


J 122LD
IGNITION SYSTEM



IGNITION SYSTEM

122 LDx


Ref	Part No	Description	Remark	QTY KIT
1	574 37 55-01	IGNITION MODULE		1
2	525 75 51-01	SCREW ITXSCFM		2
3	590 71 02-01	SPARK PLUG		1
4	537 24 96-02	FLYWHEEL		1
5	731 71 16-51	HEXAGON NUT FLANGE		1
6	574 48 89-01	SHORT CIRCUIT CABLE		1

F 122LDx
MUFFLER

MUFFLER

122 LDx


Ref	Part No	Description	Remark	QTY KIT
1	523 01 16-01	MUFFLER ASSY		1
2	525 75 51-01	SCREW ITXSCFM		3
3	522 99 73-01	GASKET		1



SHAFT

122 LDx

Ref	Part No	Description	Remark	QTY KIT
1	577 38 06-01	TUBE		1
2	574 40 75-01	DRIVE SHAFT		1
3	574 36 79-01	LOCKWASHER		2
4	577 38 07-01	TUBE		1
5	577 88 56-01	DRIVE SHAFT ASSY		1
6	576 28 26-01	CLAMPING SLEEVE ASSY		1
7	731 23 16-01	HEXAGON NUT		1
8	502 20 38-01	KNOB		1
9	725 23 76-51	SCREW EHHM		1
10	725 23 76-51	SCREW EHHM		1
11	574 29 02-01	HANDLE		1
12	577 24 50-01	SCREW		1
13	574 29 04-01	CLAMP		1
14	577 24 49-01	WING NUT		1

H 122LDx
STARTER


11

Husqvarna

STARTER

122 LDx

Ref	Part No	Description	Remark	QTY KIT	
1	574 48 74-01	STARTER ASSY		1	
2	525 83 83-01	SPRING		1	1
3	525 59 38-01	STARTER PULLEY		1	1
4	525 59 40-01	SPRING		1	1
5	525 59 39-01	DRIVER		1	1
6	577 22 61-03	SCREW ITXSCT		1	1
7	574 28 69-01	STARTER CORD		1	1
8	574 26 87-01	STARTER HANDLE		1	1
9	573 92 58-01	SCREW ITXSCFT		5	
10	525 75 51-01	SCREW ITXSCFM		3	
11	575 35 41-01	DECAL		1	
12	503 87 33-05	BRIDGE		1	

C 122LDx
THROTTLE CONTROLS

THROTTLE CONTROLS

122 LDx

Ref	Part No	Description	Remark	QTY KIT	
1	574 19 30-01	HANDLE ASSY		1	
2	575 31 58-01	STOP SWITCH		1	1
3	574 19 25-01	TRIGGER		1	1
4	574 19 24-01	THROTTLE LOCKOUT		1	1
5	576 85 17-01	SPRING		1	1
6	574 48 90-01	THROTTLE ASSY		1	1
7	574 48 88-03	SHORT CIRCUIT CABLE		1	1
8	574 44 40-01	SCREW ITXSCT		4	1
9	503 96 13-01	SCREW		2	