



232 L, 232 R 235 R, 235 R II

**Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar**

A 235
*compl 503 75 83-02 (1"/25,4mm)




A 232
*compl 502 21 92-08 (1"/25,4mm)




B


235

**B**


232




C 235R, 235RII
*compl 502 19 60-01




C 232R
*compl 503 72 43-03




D 232R
235R, 235RII
*compl 502 19 58-13




E 232L
*compl 503 78 05-03




F 232







F 235




G




H***compl 503 90 47-02****J*****compl 502 18 95-02****K*****compl 503 84 00-02****L**


M ***compl 503 79 06-01**




N ***compl 503 72 80-01 (232L,R) ø35** ***compl 503 69 46-01 (235R) ø38** ***compl 537 10 41-01 (235RII) ø40**




P ***compl 502 21 28-04**






- ① 530 03 51-73
Set of gaskets
Dichtungssatz
Jeu de joints
Juego de juntas
Packningssats

R Duo Balance
compl 537 27 57-01
compl 537 27 57-03 US




S Accessories Zubehöre Accessoires Accesorios Tillbehör


*compl 502 21 60-01




Olja Luftfilter
Oil Airfilter
Öl Luftfilter
Aceite Filtro Air
Huile Filtera aire



531 00 92-48




503 97 64-01




501 19 22-01*


(200-275 mm) 537 31 29-01





537 21 62-01
(USA) 537 21 62-02



(300mm) 502 26 23-01




(232) 503 89 01-01
(235) 503 90 18-02



503 72 49-01

503 77 39-01


(232R) 503 74 40-01
(235R, 235RII) 503 89 52-01



503 77 63-01



503 74 29-01



503 74 50-04

503 21 07-16
503 79 88-01



503 77 63-01

(235R, 235RII) 537 29 80-02
(232L, 232R) 537 29 26-01

