





326 Lx, 20041000001-20061400000




SPARE PARTS LIST

S Accessories Zubehöre Accessoires Accesorios Tillbehör





Olja Luftfilter
Oil Airfilter
Öl Luftfilter
Aceite Filtro Air
Huile Filtrera aire



531 00 92-48



*compl 501 78 33-01




compl 537 21 63-01
compl 537 21 63-02 (USA)




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
531 00 92-48	531009248	FILTER OIL		1	
501 78 33-01	501783301	SUSPENSION BAIL		1	
503 21 83-16	503218316	SCREW		1	
537 21 63-01	537216301	HARNESS		1	
537 21 63-02	537216302	HARNESS	USA	1	
503 73 40-01	503734001	FRONT PIECE		1	
503 73 41-02	503734102	BUCKLE		1	
502 02 28-02	502022802	WELT HOOK		1	
537 21 62-02	537216202	HARNESS	USA	1	
537 21 62-01	537216201	HARNESS		1	
502 03 55-05	502035505	TRANSPORT GUARD		1	
503 97 64-01	503976401	GREASE		1	
503 80 17-01	503801701	GREASE	326C	1	
502 21 58-01	502215801	WRENCH		1	
502 11 46-02	502114602	SOCKET WRENCH		1	
501 60 02-03	501600203	SCREWDRIVER		1	
502 28 59-01	502285901	STOP		1	

S Accessories Zubehöre Accessoires Acessorios Tillbehör


*compl 537 29 95-01
323R
326Rx




*compl 537 02 61-01
326C



*compl 503 93 42-02
323R
326Rx




*compl 503 97 71-01
323L
326L
326Lx
326LDx




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 29 95-01	537299501	SAW BLADE GUARD		1	
503 21 75-16	503217516	SCREW IHSCFT		4	
502 27 22-01	502272201	SAW BLADE GUARD		1	
537 29 34-01	537293401	ADAPTER		1	
537 04 75-01	537047501	CLAMP		1	
725 23 68-71	725236871	SCREW EHIHM		2	
503 93 42-02	503934202	COMBINATION GUARD		1	
503 79 88-01	503798801	BLADE		1	
503 97 71-01	503977101	TRIMMER GUARD ASSY		1	
503 21 07-16	503210716	SCREW IHSCFT		1	
537 02 61-01	537026101	TRIMMER GUARD		1	
530 05 22-86	530052286	LINE		1	

A 323L, R
326L, Lx, LDx, Rx, RJx
*compl 537 19 92-02




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 19 92-02	537199202	BEVEL GEAR ASSY		1	
738 21 98-00	738219800	BALL BEARING		1	
503 25 24-01	503252401	BALL BEARING		1	
735 31 28-10	735312810	CIRCLIP		1	
503 85 63-01	503856301	NUT		1	
537 28 56-01	537285601	SUPPORT FLANGE		1	
537 29 26-01	537292601	CUP		1	
537 23 49-01	537234901	DRIVER ASSY		1	
503 93 55-01	503935501	CLAMP GUARD		1	
735 31 25-10	735312510	CIRCLIP		1	
735 31 11-00	735311100	CIRCLIP		1	
738 21 99-02	738219902	BALL BEARING		1	
738 21 99-00	738219900	BALL BEARING		1	
503 20 07-12	503200712	SCREW IHSCFM		1	
503 20 07-25	503200725	SCREW IHSCFM		1	
725 23 70-51	725237051	SCREW		1	
503 20 14-12	503201412	SCREW IHSCFMO		1	
503 20 15-01	503201501	SCREW		1	

K




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
502 20 40-01	502204001	KNOB	326	1	
537 06 63-01	537066301	FILTER COVER	326	1	
537 14 31-01	537143101	AIR FILTER ASSY	326	1	
740 68 11-21	740681121	V-RING	326	1	
537 05 78-01	537057801	BRACKET	326	1	
503 21 75-50	503217550	SCREW IHSCFT		2	
503 88 79-01	503887901	HUB CAP		1	
731 23 14-01	731231401	HEXAGON NUT		1	
503 89 03-01	503890301	FILTER HOLDER	323	1	
503 28 31-13	503283113	CARBURETTOR	R, RX	1	
503 28 31-11	503283111	CARBURETTOR		1	
503 49 71-01	503497101	GASKET		1	
503 20 03-25	503200325	SCREW IHSCFM		2	
503 96 25-01	503962501	CHOKE CONTROL		1	
503 21 75-16	503217516	SCREW IHSCFT	323	1	
537 18 63-01	537186301	AIR FILTER	323	1	
503 94 26-01	503942601	INLET PIPE		1	
503 22 65-04	503226504	SQUARE NUT		2	
503 91 09-01	503910901	INSULATION WALL		1	
503 88 80-02	503888002	FILTER COVER	323	1	
502 20 40-02	502204002	KNOB	323	1	
502 20 65-03	502206503	SCREW EHHM	323	1	

T compl 503 28 31-11 C, L, Lx, LDx, RJx ZAMA C1Q - EL 12
 compl 503 28 31-13 R, Rx ZAMA C1Q - EL 14




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 28 31-11	503283111	CARBURETTOR	C, L, LX, LDX, RIX ZAMA C1Q - EL 12	1	
503 28 31-13	503283113	CARBURETTOR	R, RX ZAMA C1Q - EL 14	1	
537 02 09-01	537020901	SHAFT ASSY		1	
503 48 19-01	503481901	COLLAR		1	
537 04 90-01	537049001	LEVER		1	
537 02 10-01	537021001	SPRING		1	
537 02 11-01	537021101	VALVE		1	
503 47 90-01	503479001	SCREW		1	
503 48 18-01	503481801	SCREW		1	
537 01 98-01	537019801	LEVER	C, L, LX, LDX, RIX	1	
503 47 89-01	503478901	COLLAR		1	
537 01 26-01	537012601	SPRING		1	
537 01 25-01	537012501	BALL		1	
503 53 57-01	503535701	STRAINER	531 00 45-53 REPAIRKIT	1	
537 02 00-01	537020001	DIAPHRAGM PUMP	531 00 45-52 SET OF GASKETS 531 00 45-53 REPAIRKIT	1	
537 02 01-01	537020101	GASKET	531 00 45-52 SET OF GASKETS 531 00 45-53 REPAIRKIT	1	
537 02 02-01	537020201	COVER		1	
503 47 96-01	503479601	SCREW		1	
537 02 07-01	537020701	SCREW		1	
503 48 11-01	503481101	PIECE		1	
503 47 92-01	503479201	SCREW		1	
537 01 96-01	537019601	SHAFT ASSY		1	
537 01 99-01	537019901	VALVE		1	
537 01 97-01	537019701	SPRING		1	
503 75 53-01	503755301	SCREW		1	
537 02 06-01	537020601	SCREW		1	
503 97 40-01	503974001	WASHER		1	
537 12 78-01	537127801	SCREW		1	
503 48 08-01	503480801	SPRING		1	
537 02 16-01	537021601	LIMITER CAP		1	
537 02 08-01	537020801	PLUG	531 00 45-53 REPAIRKIT	1	
503 47 97-01	503479701	VALVE	531 00 45-53 REPAIRKIT	1	
537 02 03-01	537020301	SPRING	531 00 45-53 REPAIRKIT	1	
503 66 59-01	503665901	LEVER	531 00 45-53 REPAIRKIT	1	
503 48 00-01	503480001	PIN RETAINING SCREW	531 00 45-53 REPAIRKIT	1	
503 48 01-01	503480101	SCREW		1	
537 02 04-01	537020401	GASKET	531 00 45-52 SET OF GASKETS 531 00 45-53 REPAIRKIT	1	
537 04 89-01	537048901	DIAPHRAGM	531 00 45-52 SET OF GASKETS 531 00 45-53 REPAIRKIT	1	
503 97 43-01	503974301	COVER		1	
503 48 05-01	503480501	SCREW		2	

H 323L, R




J 326C, L, Lx, LDx, RX, RJx



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 21 35-12	503213512	SCREW CCRPANT		1	
503 97 21-01	503972101	COVER	RX	1	
503 96 13-01	503961301	SCREW	RX	2	
537 06 61-01	537066101	CYLINDER COVER		1	
503 98 12-41	503981241	LABEL		1	
731 23 14-01	731231401	HEXAGON NUT		1	
503 21 71-16	503217116	SCREW IHSC T		1	
503 98 12-42	503981242	LABEL		1	
537 06 65-01	537066501	HEAT PROTECTOR		1	
503 21 68-20	503216820	SCREW IHSC FT		1	
537 06 66-01	537066601	ARM PROTECTION		1	
537 10 44-01	537104401	ARM PROTECTION		1	
537 32 02-01	537320201	CYLINDER COVER		1	
537 32 08-01	537320801	HEAT PROTECTOR		1	


Q

*compl 537 08 52-01
**compl 537 04 12-03



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 08 52-01	537085201	CRANKCASE		1	
537 04 12-03	537041203	CLUTCH COVER		1	
537 30 96-01	537309601	SLEEVE		1	
503 21 68-20	503216820	SCREW IHSCFT		3	
503 87 26-01	503872601	CLUTCH DRUM ASSY		1	
503 21 66-18	503216618	SCREW IHSCFT		1	
503 21 71-18	503217118	SCREW IHSCFT		1	
537 06 68-01	537066801	INSERT CRANKCASE		1	
537 07 36-01	537073601	SPRING		1	
537 08 85-01	537088501	GASKET		1	
537 06 69-01	537066901	GASKET		1	
503 21 68-25	503216825	SCREW IHSCFT		2	

R *compl 503 85 24-74



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 85 24-74	503852474	CRANKSHAFT ASSY		1	
503 94 02-01	503940201	BEARING CAGE		1	
503 94 05-01	503940501	CUP		1	
503 71 22-01	503712201	BEARING		1	

P *compl 537 08 51-01

326 **537 22 18-01

326 **compl 537 22 17-01 Cat.

326 **503 20 29-56 (x3)

537 01 41-01

*

** 326

503 28 90-43 (x2)

503 20 07-35* (x4)

503 71 22-01

737 44 08-00 (x2)


537 08 46-71*

323 ***compl 537 03 94-01 Cat.

323 ***503 20 29-50 (x3)


323 ***

323 ***503 87 17-01



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 08 51-01	537085101	PISTON		1	
537 22 18-01	537221801	SPARK ARRESTER SCREEN	326	1	
537 01 41-01	537014101	GASKET		1	
503 28 90-43	503289043	PISTON RING		2	
503 71 22-01	503712201	BEARING		1	
737 44 08-00	737440800	CIRCLIP		2	
537 08 46-71	537084671	PISTON		1	
503 20 07-35	503200735	SCREW IHSCFM		4	
503 87 17-01	503871701	SPARK ARRESTER SCREEN	323	1	
503 20 29-50	503202950	SCREW IHSCFM	323	3	
537 03 94-01	537039401	MUFFLER ASSY	323 CAT.	1	
503 20 29-56	503202956	SCREW IHSCFM	326	3	
537 22 17-01	537221701	MUFFLER ASSY	326 CAT.	1	

M *compl 537 06 86-01 C, L, Lx, R, RJx, Rx
 *compl 537 06 86-02 LDx




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 06 86-01	537068601	FUEL TANK	C, L, LX, R, RJX, RX	1	
537 06 86-02	537068602	FUEL TANK	LDX	1	
503 93 66-01	503936601	PURGE		1	
537 04 24-01	537042401	FUEL HOSE		2	
503 57 76-01	503577601	FUEL HOSE	LDX	1	
503 44 32-01	503443201	FUEL FILTER	LDX	1	
537 18 49-01	537184901	O-RING	LDX	1	
503 91 10-01	503911001	SUSPENSION		4	
537 05 23-01	537052301	FUEL HOSE		1	
503 73 58-01	503735801	BUSHING		2	
503 91 18-02	503911802	TANK CAP		1	

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 27 57-01	537275701	HARNESS		1	
537 27 57-03	537275703	HARNESS	US	1	
537 17 54-01	537175401	HIP PAD		3	
537 27 59-01	537275901	HIP PAD		1	
503 99 61-03	503996103	BAND		1	
537 11 35-01	537113501	RETAINER		1	
537 28 84-01	537288401	BUCKLE		1	
537 28 83-01	537288301	BUCKLE		1	
503 99 61-01	503996101	BAND		1	
502 02 28-01	502022801	HOOK		1	
735 31 09-20	735310920	E-CLIP		1	
502 02 29-02	502022902	HOOK		1	
502 02 38-01	502023801	SPRING		1	
502 02 30-02	502023002	LOCK		1	

N


***compl 537 04 23-01**

****compl 537 06 33-02 (326)**




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 04 23-01	537042301	IGNITION MODULE		1	
503 84 29-02	503842902	SCREW		2	
537 04 67-01	537046701	WASHER		1	
503 81 60-01	503816001	CLUTCH SPRING		1	
503 84 28-01	503842801	CLUTCH SHOE		2	
537 03 22-01	537032201	CLUTCH ASSY		1	
537 04 68-01	537046801	WASHER		1	
731 71 16-51	731711651	HEXAGON NUT FLANGE		1	
537 24 96-01	537249601	FLYWHEEL		1	
503 21 71-16	503217116	SCREW IHSCT		2	
503 23 51-09	503235109	SPARK PLUG	CHAMPION RCJ 6Y	1	
537 09 17-01	537091701	SECURING PLATE		1	
537 23 96-01	537239601	SPARK PLUG CAP		1	
537 06 44-03	537064403	COVER		1	
537 06 33-02	537063302	COVER	326	1	

C 323L
326L, Lx
326RJx




D 326LDx
*compl 537 07 99-01



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 07 99-01	537079901	TUBE		1	
735 58 08-10	735580810	LOCKWASHER		1	
537 08 27-01	537082701	TUBE		1	
503 70 80-04	503708004	SLEEVE		1	
503 71 54-01	503715401	LOCKING PLATE		1	
503 78 52-01	503785201	SUPPORTING BEARING		1	
537 29 48-01	537294801	LABEL		1	
503 79 56-01	503795601	LABEL		1	
503 98 54-01	503985401	BEARING CAGE		1	
537 01 16-01	537011601	TUBE		1	
503 20 02-10	503200210	SCREW IHSCFM		1	
537 08 30-01	537083001	DRIVE SHAFT		1	
503 20 07-25	503200725	SCREW IHSCFM		2	
537 01 19-01	537011901	DRIVE SHAFT		1	
502 20 38-01	502203801	KNOB		1	
725 23 79-51	725237951	SCREW EHHM		1	

C 323L
326L, Lx
326RJx



537 29 48-01



503 79 56-01




537 10 10-01 (RJx)

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 23 00-61	503230061	WASHER		1	
503 79 56-01	503795601	LABEL		1	
503 87 19-01	503871901	HANDLE LOOP		1	
503 87 19-03	503871903	HANDLE		1	
503 88 88-01	503888801	TUBE		1	
503 86 45-01	503864501	DRIVE SHAFT		1	
503 87 90-01	503879001	KNOB		1	
503 87 26-01	503872601	CLUTCH DRUM ASSY		1	
537 29 48-01	537294801	LABEL		1	
503 94 03-01	503940301	DISTANCE		1	
502 19 71-01	502197101	SQUARE NUT		1	
503 99 78-01	503997801	HANDLE		1	
537 10 10-01	537101001	LABEL		1	
503 94 10-01	503941001	HOOK		1	
503 20 07-16	503200716	SCREW IHSCFM		1	
725 23 78-51	725237851	SCREW EHHM		1	
725 23 80-51	725238051	SCREW EHHM		1	
731 23 14-01	731231401	HEXAGON NUT		1	
503 21 68-16	503216816	SCREW IHSCT		4	

L

****compl 503 87 33-02**


***compl 503 85 28-01**




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 87 33-02	503873302	BRIDGE		1	
735 31 08-20	735310820	E-CLIP		1	
731 71 16-51	731711651	HEXAGON NUT FLANGE		1	
503 21 77-16	503217716	SCREW IH SCT		1	
503 87 36-01	503873601	SPRING		1	
503 87 35-02	503873502	STARTER PAWL		1	
503 96 49-01	503964901	STARTER PULLEY		1	
537 03 41-01	537034101	PROTECTIVE PLATE		1	
503 21 66-18	503216618	SCREW IH SCT		1	
503 21 68-20	503216820	SCREW IH SCFT		1	
537 35 34-34	537353434	LABEL	326RJX	1	
503 97 98-45	503979845	DECAL	323R	1	
503 97 98-44	503979844	DECAL	323L	1	
537 17 22-20	537172220	LABEL	326LDX	1	
537 17 22-05	537172205	LABEL	326L	1	
537 17 22-04	537172204	LABEL	326C	1	
537 17 22-03	537172203	LABEL	326RX	1	
537 17 22-02	537172202	LABEL	326LX	1	
503 85 87-01	503858701	STARTER HOUSING		1	
537 00 84-01	537008401	STARTER HANDLE		1	
503 85 89-01	503858901	STARTER ROPE		1	
503 85 28-01	503852801	STARTER ASSY		1	

F

323L
326C, L, Lx, LDx, RJx
*compl 503 85 29-02

**G**

323R
326Rx
*compl 537 18 35-07



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 20 07-35	503200735	SCREW IHSCFM		1	
503 21 66-16	503216616	SCREW IH SCT		1	
503 85 29-02	503852902	HANDLE		1	
503 91 81-01	503918101	THROTTLE LEVER		1	
503 22 10-13	503221013	HEXAGON NUT		1	
503 87 79-01	503877901	THROTTLE TRIGGER		1	
503 99 56-01	503995601	HANDLE HALF	C, L	1	
503 99 56-02	503995602	HANDLE HALF	LX, LDX	1	
503 87 85-01	503878501	SHORT CIRCUIT CABLE		1	
503 87 86-01	503878601	THROTTLE CABLE ASSY		1	
503 99 55-02	503995502	HANDLE HALF	LX, LDX	1	
503 99 55-01	503995501	HANDLE HALF	C, L	1	
503 87 80-01	503878001	THROTTLE LOCKOUT		1	
537 01 13-01	537011301	RECOIL SPRING		1	
740 42 06-00	740420600	O-RING		1	
503 96 13-01	503961301	SCREW		1	
503 21 66-18	503216618	SCREW IH SCT		5	
503 71 82-01	503718201	SWITCH		1	
537 07 39-02	537073902	ANTIVIBRATION ELEMENT	C	1	
537 16 02-09	537160209	HANDLE HALF	Without hole for Steering wheel assy	1	
537 16 02-02	537160202	HANDLE HALF	Replaced by 537 18 35-07 HANDLE SYSTEM cpl	1	
503 96 14-01	503961401	ABSORBER	L, LX, LDX	1	
537 16 03-02	537160302	HANDLE HALF		1	
537 16 06-01	537160601	THROTTLE LOCKOUT		1	
537 16 07-01	537160701	THROTTLE LOCKOUT		1	
537 16 08-01	537160801	THROTTLE TRIGGER		1	
537 16 09-01	537160901	STEERING WHEEL	Does not fit with HANDLE HALF 537 16 02-09	1	
537 16 10-01	537161001	HUB	Does not fit with HANDLE HALF 537 16 02-09	1	
537 16 12-01	537161201	SCREW	Does not fit with HANDLE HALF 537 16 02-09	1	
537 17 39-01	537173901	THROTTLE CABLE ASSY		1	
537 17 40-01	537174001	WIRING ASSY		1	
537 17 42-01	537174201	SPRING THROTTLE TRIG		1	
537 17 43-01	537174301	SPRING		1	
537 17 44-01	537174401	SPRING	Does not fit with HANDLE HALF 537 16 02-09	1	
537 18 35-07	537183507	HANDLE ASSY		1	
537 18 36-01	537183601	SPRING	Does not fit with HANDLE HALF 537 16 02-09	1	