


326 RJX, 20070100001-20091800000

SPARE PARTS LIST


Y Duo Balance
***compl 537 27 57-01**
***compl 537 27 57-03 US**



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 27 57-01	537275701	HARNESS		1	
537 27 57-03	537275703	HARNESS		1	
503 99 61-01	503996101	BAND		1	
503 99 61-03	503996103	BAND		1	
537 17 54-01	537175401	HIP PAD		3	
537 27 59-01	537275901	HIP PAD		1	
537 11 35-01	537113501	RETAINER		1	
537 28 84-01	537288401	BUCKLE		1	
537 28 83-01	537288301	BUCKLE		1	
735 31 09-20	735310920	E-CLIP		1	
502 02 29-02	502022902	HOOK		1	
502 02 38-01	502023801	SPRING		1	
502 02 30-02	502023002	LOCK		1	
502 02 28-01	502022801	HOOK		1	


R 323

***compl 537 03 20-08 Ø=34mm**




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 03 20-08	537032008	CYLINDER		1	
537 01 41-01	537014101	GASKET		1	
537 40 62-01	537406201	PISTON RING		2	
737 44 08-00	737440800	CIRCLIP		2	
503 71 22-01	503712201	BEARING		1	
537 40 59-02	537405902	PISTON		1	
725 53 37-55	725533755	SCREW IHSCM		4	
537 03 94-05	537039405	MUFFLER ASSY		1	
503 87 17-01	503871701	SPARK ARRESTER SCREEN		1	
503 20 29-50	503202950	SCREW IHSCFM		2	

K *compl 544 07 11-02



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
544 07 11-02	544071102	STARTER ASSY		1	
503 87 33-05	503873305	STARTER PAWL		1	
735 31 08-20	735310820	E-CLIP		2	
503 87 36-01	503873601	SPRING		2	
503 87 35-02	503873502	STARTER PAWL		2	
503 21 77-25	503217725	SCREW IH SCT		1	
544 03 87-01	544038701	DRIVER		1	
544 03 88-01	544038801	SPRING		1	
544 16 65-01	544166501	STARTER PULLEY ASSY		1	
537 03 41-01	537034101	PROTECTIVE PLATE		1	
503 20 03-16	503200316	SCREW IH SCFM		1	
503 21 66-18	503216618	SCREW IH SCT		1	
537 41 16-01	537411601	STARTER HOUSING		1	
503 85 90-01	503859001	RECOIL SPRING		1	
544 03 86-01	544038601	STARTER PULLEY		1	
503 21 68-20	503216820	SCREW IH SCFT		1	
537 37 93-02	537379302	SPACING SLEEVE		1	
537 00 84-01	537008401	STARTER HANDLE		1	
503 85 89-01	503858901	STARTER ROPE		1	
537 35 34-34	537353434	LABEL		1	
537 35 34-07	537353407	LABEL		1	
537 35 34-04	537353404	LABEL		1	
537 35 34-32	537353432	LABEL		1	
537 35 34-33	537353433	LABEL		1	
537 35 34-31	537353431	LABEL		1	

G 323L, R




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 35 33-14	537353314	LABEL		1	
537 35 33-16	537353316	LABEL		1	
503 97 21-01	503972101	COVER		1	
503 96 13-01	503961301	SCREW		2	
503 87 18-02	503871802	CYLINDER COVER		1	
503 21 68-20	503216820	SCREW IHSCFT		1	
537 32 08-03	537320803	HEAT PROTECTOR		1	
503 20 03-16	503200316	SCREW IHSCFM		3	
537 10 44-01	537104401	ARM PROTECTION		1	
503 21 35-12	503213512	SCREW CCRPANT		2	

Q 326

*compl 537 08 52-02


**compl 537 04 12-07

***compl 537 30 96-01




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 08 52-02	537085202	CRANKCASE		1	
537 04 12-07	537041207	CLUTCH COVER		1	
537 30 96-01	537309601	SLEEVE		1	
503 21 68-25	503216825	SCREW IHSCFT		2	
537 42 50-01	537425001	PROTECTIVE PLATE		1	
503 20 03-16	503200316	SCREW IHSCFM		8	
503 21 77-16	503217716	SCREW IHSCFT		1	
503 20 14-12	503201412	SCREW IHSCFMO		1	
503 21 66-18	503216618	SCREW IHSCFT		1	
537 07 36-01	537073601	SPRING		1	
537 08 85-01	537088501	GASKET		1	
537 06 69-01	537066901	GASKET		1	
537 06 68-01	537066801	INSERT CRANKCASE		1	

L *compl 503 85 28-06 **326LS**




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 85 28-06	503852806	STARTER ASSY		1	
503 87 33-05	503873305	STARTER PAWL		1	
735 31 08-20	735310820	E-CLIP		2	
503 87 36-01	503873601	SPRING		2	
503 87 35-02	503873502	STARTER PAWL		2	
537 03 41-01	537034101	PROTECTIVE PLATE		1	
503 20 03-16	503200316	SCREW IHSCFM		1	
503 21 66-18	503216618	SCREW IH SCT		1	
503 96 49-01	503964901	STARTER PULLEY		1	
503 21 77-16	503217716	SCREW IH SCT		1	
537 37 93-02	537379302	SPACING SLEEVE		2	
537 35 34-54	537353454	LABEL		1	
503 85 89-01	503858901	STARTER ROPE		1	
537 00 84-01	537008401	STARTER HANDLE		1	
503 85 87-02	503858702	STARTER HOUSING		1	

A *compl 537 19 92-02



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 19 92-02	537199202	BEVEL GEAR ASSY		1	
738 21 98-00	738219800	BALL BEARING		1	
503 25 24-01	503252401	BALL BEARING		1	
735 31 28-10	735312810	CIRCLIP		1	
537 23 49-01	537234901	DRIVER ASSY		1	
537 29 26-01	537292601	CUP		1	
537 28 56-01	537285601	SUPPORT FLANGE		1	
503 85 63-01	503856301	NUT		1	
503 93 55-01	503935501	CLAMP GUARD		1	
735 31 25-10	735312510	CIRCLIP		1	
735 31 11-00	735311100	CIRCLIP		1	
738 21 99-02	738219902	BALL BEARING		1	
738 21 99-00	738219900	BALL BEARING		1	
503 20 07-12	503200712	SCREW IHSCFM		1	
503 20 07-25	503200725	SCREW IHSCFM		1	
725 23 70-51	725237051	SCREW		1	
503 20 14-12	503201412	SCREW IHSCFMO		1	
503 20 15-01	503201501	SCREW		1	

J



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
502 20 65-03	502206503	SCREW EHHM		1	
502 20 40-02	502204002	KNOB		1	
503 88 80-02	503888002	FILTER COVER		1	
537 21 32-10	537213210	KNOB		1	
537 06 63-02	537066302	FILTER COVER		1	
537 14 31-01	537143101	AIR FILTER ASSY		1	
740 68 11-21	740681121	V-RING		1	
537 05 78-01	537057801	BRACKET		1	
503 21 75-50	503217550	SCREW IHSCFT		2	
503 88 79-01	503887901	HUB CAP		1	
731 23 14-01	731231401	HEXAGON NUT		1	
503 89 03-01	503890301	FILTER HOLDER		1	
503 28 34-01	503283401	CARBURETTOR		1	
503 49 71-01	503497101	GASKET		1	
503 20 03-25	503200325	SCREW IHSCFM		2	
503 94 26-01	503942601	INLET PIPE		1	
503 22 65-04	503226504	SQUARE NUT		2	
503 96 25-01	503962501	CHOKE CONTROL		1	
503 21 75-16	503217516	SCREW IHSCFT		1	
537 18 63-01	537186301	AIR FILTER		1	
503 91 09-01	503910901	INSULATION WALL		1	


S

323

***compl 537 04 11-03**


****compl 537 04 12-07**

***compl 537 30 96-01



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 04 11-03	537041103	CRANKCASE		1	
537 04 12-07	537041207	CLUTCH COVER		1	
537 30 96-01	537309601	SLEEVE		1	
503 21 68-25	503216825	SCREW IHSCFT		2	
537 42 50-01	537425001	PROTECTIVE PLATE		1	
537 07 36-01	537073601	SPRING		1	
503 20 03-16	503200316	SCREW IHSCFM		8	
503 21 66-18	503216618	SCREW IH SCT		1	
503 20 14-12	503201412	SCREW IHSCFMO		1	


E 323L
326Lx, LS, LDx, RJx
 *compl 503 85 29-02



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 85 29-02	503852902	HANDLE		1	
503 91 81-01	503918101	THROTTLE LEVER		1	
503 87 79-03	503877903	THROTTLE TRIGGER		1	
503 99 56-01	503995601	HANDLE HALF		1	
503 99 56-02	503995602	HANDLE HALF		1	
740 42 06-00	740420600	O-RING		1	
503 96 13-01	503961301	SCREW		1	
544 17 17-01	544171701	THROTTLE CABLE ASSY		1	
503 99 55-02	503995502	HANDLE HALF		1	
503 99 55-01	503995501	HANDLE HALF		1	
503 87 80-01	503878001	THROTTLE LOCKOUT		1	
537 01 13-01	537011301	RECOIL SPRING		1	
503 96 14-01	503961401	ABSORBER		1	
537 41 90-01	537419001	SWITCH		1	
503 21 66-18	503216618	SCREW IHSCT		5	
537 41 42-01	537414201	SHORT CIRCUIT CABLE		1	


N *compl 537 41 87-01

****compl 537 06 33-02 (326)**



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 41 87-01	537418701	IGNITION MODULE		1	
503 84 29-02	503842902	SCREW		2	
503 81 60-01	503816001	CLUTCH SPRING		1	
503 84 28-01	503842801	CLUTCH SHOE		2	
537 03 22-01	537032201	CLUTCH ASSY		1	
537 04 67-02	537046702	WASHER		1	
537 04 68-02	537046802	WASHER		1	
731 71 16-51	731711651	HEXAGON NUT FLANGE		1	
537 24 96-02	537249602	FLYWHEEL		1	
503 21 71-16	503217116	SCREW IHSCT		2	
537 09 17-01	537091701	SECURING PLATE		1	
537 23 96-01	537239601	SPARK PLUG CAP		1	
537 06 44-03	537064403	COVER		1	
537 06 33-02	537063302	COVER		1	
503 23 51-09	503235109	SPARK PLUG		1	

T *compl 503 85 24-74 (326)
**compl 503 85 24-75 (323)



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 85 24-74	503852474	CRANKSHAFT ASSY		1	
503 85 24-75	503852475	CRANKSHAFT ASSY		1	
503 94 02-03	503940203	BEARING CAGE		1	
503 94 05-01	503940501	CUP		1	
503 71 22-01	503712201	BEARING		1	

P 326


*compl 537 08 51-02 Ø=34mm

**537 22 18-01


**compl 537 22 17-03 Cat.

503 20 29-56 (x3)

537 01 41-01




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 08 51-02	537085102	PISTON		1	
537 22 18-01	537221801	SPARK ARRESTER SCREEN		1	
537 01 41-01	537014101	GASKET		1	
537 40 62-01	537406201	PISTON RING		2	
503 71 22-01	503712201	BEARING		1	
737 44 08-00	737440800	CIRCLIP		2	
537 40 59-02	537405902	PISTON		1	
503 20 07-35	503200735	SCREW IHSCFM		4	
503 20 29-56	503202956	SCREW IHSCFM		3	
537 22 17-03	537221703	MUFFLER ASSY		1	



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 28 34-01	503283401	CARBURETTOR		1	
503 48 19-01	503481901	COLLAR		1	
537 04 90-01	537049001	LEVER		1	
537 02 10-01	537021001	SPRING		1	
537 37 03-01	537370301	VALVE		1	
503 48 18-01	503481801	SCREW		1	
503 47 90-01	503479001	SCREW		1	
537 01 98-01	537019801	LEVER		1	
503 47 89-01	503478901	COLLAR		1	
537 01 26-01	537012601	SPRING		1	
537 01 25-01	537012501	BALL		1	
503 53 57-01	503535701	STRAINER		1	
537 02 00-01	537020001	DIAPHRAGM PUMP		1	
537 02 01-01	537020101	GASKET		1	
537 02 02-01	537020201	COVER		1	
503 47 96-01	503479601	SCREW		1	
537 02 07-01	537020701	SCREW		1	
503 48 11-01	503481101	PIECE		1	
503 47 92-01	503479201	SCREW		1	
537 01 96-01	537019601	SHAFT ASSY		1	
537 01 99-01	537019901	VALVE		1	
537 01 97-01	537019701	SPRING		1	
503 75 53-01	503755301	SCREW		1	
537 02 06-01	537020601	SCREW		1	
503 97 40-01	503974001	WASHER		1	
537 02 16-01	537021601	LIMITER CAP		1	
537 12 78-01	537127801	SCREW		1	
503 48 08-01	503480801	SPRING		1	
537 02 08-01	537020801	PLUG		1	
503 47 97-01	503479701	VALVE		1	
537 02 03-01	537020301	SPRING		1	
503 66 59-01	503665901	LEVER		1	
503 48 00-01	503480001	PIN RETAINING SCREW		1	
503 48 01-01	503480101	SCREW		1	
537 02 04-01	537020401	GASKET		1	
537 04 89-01	537048901	DIAPHRAGM		1	
503 97 43-01	503974301	COVER		1	
503 48 05-01	503480501	SCREW		2	



D 323R
326Rx
 *compl 503 72 43-09



537 29 48-01

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 72 43-09	503724309	HANDLEBAR		1	
537 17 28-01	537172801	HANDLE		1	
537 17 29-01	537172901	COVER		1	
503 20 02-45	503200245	SCREW IHSCFM		1	
503 88 88-01	503888801	TUBE		1	
502 21 12-01	502211201	STAPLE		1	
503 21 75-25	503217525	SCREW IHSCFT		2	
502 19 71-01	502197101	SQUARE NUT		1	
537 23 48-01	537234801	DRIVE SHAFT		1	
537 29 48-01	537294801	LABEL		1	
537 23 75-01	537237501	CLUTCH DRUM ASSY		1	
735 31 12-00	735311200	CIRCLIP		1	
503 94 10-01	503941001	HOOK		1	
503 20 07-16	503200716	SCREW IHSCFM		1	
503 88 23-01	503882301	BRACKET		1	
503 75 00-01	503750001	HANDLEBAR BRACKET		1	
731 23 14-01	731231401	HEXAGON NUT		1	
503 72 29-01	503722901	COVER		1	
502 20 38-01	502203801	KNOB		1	
725 23 86-51	725238651	SCREW EHHM		1	

C 326LDx
***compl 537 07 99-01**




537 29 48-01 503 79 56-01



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 07 99-01	537079901	TUBE		1	
537 08 27-01	537082701	TUBE		1	
503 70 80-04	503708004	SLEEVE		1	
503 71 54-01	503715401	LOCKING PLATE		1	
503 78 52-01	503785201	SUPPORTING BEARING		1	
537 29 48-01	537294801	LABEL		1	
503 79 56-01	503795601	LABEL		1	
503 98 54-01	503985401	BEARING CAGE		1	
503 20 02-10	503200210	SCREW IHSCFM		1	
537 01 16-01	537011601	TUBE		1	
544 11 37-01	544113701	DRIVE SHAFT ASSY		1	
503 20 07-25	503200725	SCREW IHSCFM		2	
735 58 08-10	735580810	LOCKWASHER		1	
537 01 19-01	537011901	DRIVE SHAFT		1	
502 20 38-01	502203801	KNOB		1	
725 23 79-51	725237951	SCREW EHHM		1	


B 323L
326Lx
326RJx
326LS




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 88 88-01	503888801	TUBE		1	
503 99 78-01	503997801	HANDLE		1	
502 19 71-01	502197101	SQUARE NUT		1	
537 23 48-01	537234801	DRIVE SHAFT		1	
537 29 48-01	537294801	LABEL		1	
503 79 56-01	503795601	LABEL		1	
537 10 10-01	537101001	LABEL		1	
537 23 75-01	537237501	CLUTCH DRUM ASSY		1	
735 31 12-00	735311200	CIRCLIP		1	
503 21 68-16	503216816	SCREW IH SCT		3	
731 23 14-01	731231401	HEXAGON NUT		1	
503 94 10-01	503941001	HOOK		1	
503 20 07-16	503200716	SCREW IH SCFM		1	
503 94 03-01	503940301	DISTANCE		1	
503 87 19-03	503871903	HANDLE		1	
503 87 19-01	503871901	HANDLE LOOP		1	
503 23 00-61	503230061	WASHER		1	
503 87 90-01	503879001	KNOB		1	
725 23 80-51	725238051	SCREW EHHM		1	
725 23 78-51	725237851	SCREW EHHM		1	

U Accessories **Zubehöre** **Accessoires** **Accessorios** **Tillbehör**


***compl 537 29 95-01**
323R
326Rx



***compl 503 93 42-02**
323R
326Rx




***compl 503 97 71-01**
323L
326Lx
326LDx
326LS



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 29 95-01	537299501	SAW BLADE GUARD		1	
503 21 75-16	503217516	SCREW IHSCFT		4	
502 27 22-01	502272201	SAW BLADE GUARD		1	
537 29 34-01	537293401	ADAPTER		1	
537 04 75-01	537047501	CLAMP		1	
725 23 68-71	725236871	SCREW EHIHM		2	
503 93 42-02	503934202	COMBINATION GUARD		1	
503 21 07-16	503210716	SCREW IHSCFT		1	
503 97 71-01	503977101	TRIMMER GUARD ASSY		1	
503 79 88-01	503798801	BLADE		1	

M *compl 537 06 86-02





REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
537 06 86-02	537068602	FUEL TANK		1	
503 93 66-01	503936601	PURGE		1	
503 73 58-01	503735801	BUSHING		2	
544 32 50-01	544325001	FUEL HOSE		1	
537 18 49-01	537184901	O-RING		1	
503 44 32-01	503443201	FUEL FILTER		1	
537 04 24-01	537042401	FUEL HOSE		2	
503 91 10-01	503911001	SUSPENSION		4	
503 91 18-02	503911802	TANK CAP		1	


X Accessories **Zubehöre** **Accessoires** **Accesorios** **Tillbehör**

Olja Luftfilter
 Oil Airfilter
 Öl Luftfilter
 Aceite Filtro Air
 Huile Filtera aire


531 00 92-48



502 28 59-01



501 60 02-03





502 11 46-02




502 21 58-01

compl 537 35 36-01




503 97 64-01


537 31 29-01 (200-275 mm)



compl 537 21 63-01
 compl 537 21 63-02 (USA)



537 21 62-01
 537 21 62-02 (USA)




503 73 40-01
 503 73 41-02

502 02 28-02

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
502 28 59-01	502285901	STOP		1	
501 60 02-03	501600203	SCREWDRIVER		1	
531 00 92-48	531009248	FILTER OIL		1	
537 35 36-01	537353601	LOOP		1	
537 35 01-01	537350101	LOOP		1	
725 23 31-51	725233151	SCREW		1	
537 21 62-01	537216201	HARNESS		1	
537 21 62-02	537216202	HARNESS		1	
502 02 28-02	502022802	WELT HOOK		1	
503 73 41-02	503734102	BUCKLE		1	
503 73 40-01	503734001	FRONT PIECE		1	
537 21 63-02	537216302	HARNESS		1	
537 21 63-01	537216301	HARNESS		1	
537 31 29-01	537312901	TRANSPORT GUARD		1	
537 13 04-02	537130402	KNOB		1	
503 97 64-01	503976401	GREASE		1	
502 21 58-01	502215801	WRENCH		1	
502 11 46-02	502114602	SOCKET WRENCH		1	

H 326Lx, LDx, RX, RJx, LS



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
503 21 68-20	503216820	SCREW IHSCFT		3	
503 20 03-16	503200316	SCREW IHSCFM		3	
503 97 21-01	503972101	COVER		1	
503 96 13-01	503961301	SCREW		2	
537 06 61-02	537066102	CYLINDER COVER		1	
503 22 24-01	503222401	LOCK NUT		1	
544 90 85-01	544908501	WASHER		1	
503 21 71-16	503217116	SCREW IHSCFT		1	
537 06 65-02	537066502	HEAT PROTECTOR		1	
537 06 66-01	537066601	ARM PROTECTION		1	