




SPARE PARTS LIST

TRIMMERS/EDGERS




327 LS, 2009, 2010

S2 327LX, LDX, RX, RDX, RJX, 323Rii, 327LS
ACCESSORIES

ACCESSORIES

327 LS, 2009, 2010


Ref	Part No	Description	Remark	QTY KIT	
1	502 28 59-01	STOP		1	
2	502 11 46-02	SOCKET WRENCH		1	
3	501 60 02-03	SCREWDRIVER		1	
4	502 21 58-01	L-NYCKEL		1	
5	531 00 92-48	FILTER OIL		1	
6	501 69 17-01	COMBINATION WRENCH		1	
7	503 97 64-01	GREASE		1	
8	537 35 36-01	LOOP		1	
9	537 13 04-02	KNOB		1	
10	537 35 01-01	LOOP		1	
11	725 23 31-51	SCREW		1	
12	537 31 29-01	TRANSPORT GUARD	200-275 mm	1	
13	537 21 62-01	HARNESS		1	
13	537 21 62-02	HARNESS	USA	1	
14	537 21 63-01	HARNESS		1	
14	537 21 63-02	HARNESS	USA	1	
15	503 73 40-01	FRONT PIECE		1	14
16	503 73 41-02	FRONT PIECE		1	14
17	502 02 28-02	WELT HOOK		1	14

S 327LS, LX, LDX, RX, RDX, RJX, 323RII
ACCESSORIES

ACCESSORIES

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT	
1	544 04 42-10	ACCESSORY BAG	Captive screws 323RII, 327Rx	1	
2	573 99 43-04	SCREW IHSCFMO	Captive screws	2	1
3	574 56 80-01	CLAMP	Captive screws	1	1
4	537 29 34-01	ADAPTER		1	1
5	574 56 49-02	BLADE GUARD	Captive screws	1	1
6	503 20 03-16	SCREW IHSCFM	Captive screws	4	1
7	574 03 95-01	LOCKING NUT	Captive screws	4	1
8	503 97 71-01	TRIMMER GUARD	327Lx, 327LDx	1	
9	503 21 07-16	SCREW IH SCT		1	8
10	503 79 88-01	BLADE		1	8
11	503 93 42-02	COMBI GUARD	323RII, 327Rx	1	
12	503 21 07-16	SCREW IH SCT		1	11
13	503 79 88-01	BLADE		1	11

A 327LS, LX, LDX, RX, RDX, RJX, 323Rll
BEVEL GEAR


BEVEL GEAR

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT	
1	537 19 92-02	BEVEL GEAR ASSY		1	
2	503 85 63-01	NUT		1	1
3	537 28 56-01	SUPPORT FLANGE		1	1
4	537 29 26-01	CUP		1	1
5	537 23 49-01	DRIVER ASSY		1	1
6	735 31 28-10	CIRCLIP		1	1
7	503 25 24-01	BALL BEARING		1	1
8	738 21 98-00	BALL BEARING		1	1
9	503 20 15-01	SCREW IHHM		1	1
10	503 20 14-12	SCREW IHSCFMO		1	1
11	503 20 07-25	SCREW IHSCFM		1	1
12	738 21 99-00	BALL BEARING		1	1
13	738 21 99-02	BALL BEARING		1	1
14	735 31 11-00	CIRCLIP		1	1
15	735 31 25-10	CIRCLIP		1	1
16	725 23 70-51	SCREW		1	18
17	503 20 07-12	SCREW IHSCFM		1	18
18	574 30 69-01	CLAMP	Captive screws	1	
20	537 33 37-01	GEAR HOUSING		1	

CARBURETOR (only option for US)


Hualong HQ-2



CARBURETOR

327 LS, 2009, 2010


Ref	Part No	Description	Remark	QTY KIT	
1	576 01 98-01	CARBURETTOR	Hualong HQ-2, only option for US	1	
2	576 02 42-01	SCREW		2	1
4	576 02 36-01	COVER		1	1
5	576 02 24-01	DIAPHRAGM ASSY		1	1
6	576 02 30-01	SHAFT ASSY		1	1
7	576 02 41-01	SCREW		1	1
8	576 02 32-01	CHOKE		1	1
9	576 02 48-01	E-CLIP		1	1
10	576 02 31-01	LEVER		1	1
11	576 02 35-01	BUSHING		1	1
12	576 02 33-01	SPRING		1	1
14	576 02 01-01	VALVE		1	1
15	576 02 37-01	GASKET		1	1
16	576 02 03-01	PIN		1	1
17	576 02 04-01	LEVER		1	1
18	576 02 05-01	SPRING		1	1
19	576 02 06-01	PLUG		1	1
20	576 02 28-01	LEVER		1	1
21	576 02 29-01	BUSHING		1	1
22	576 02 07-01	MAIN NOZZLE		1	1
23	576 02 08-01	CHECK VALVE		1	1
24	576 02 43-01	SCREW		1	1
25	576 02 34-01	SPRING		1	1
26	576 02 47-01	BALL		1	1
27	576 02 23-01	BAR		1	1
28	576 02 10-01	NEEDLE		1	1
29	576 02 11-01	NEEDLE		1	1
30	576 02 15-01	SCREEN		1	1
31	576 02 27-01	SPRING		1	1
32	576 02 40-01	SCREW		1	1
33	576 02 26-01	THROTTLE		1	1
34	576 02 39-01	DIAPHRAGM PUMP		1	1
35	576 02 25-01	SHAFT ASSY		1	1
36	576 02 38-01	GASKET		1	1
37	576 02 20-01	COVER		1	1
38	576 02 22-01	SCREW		1	1
39	576 02 44-01	SCREW		1	1
40	581 74 35-01	GASKET KIT		1	1
41	581 74 37-01	REPAIR KIT		1	1

H3 327LS
COVERS


CARBURETOR & AIR FILTER

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT
1	505 14 20-01	FILTER COVER		1
2	505 14 22-01	COVER		1
3	574 47 70-03	SCREW IHSCFMO		4
4	503 21 35-12	SCREW CCRPANT		2
5	502 48 16-01	ARM PROTECTION		1
6	544 84 81-02	HEAT PROTECTOR		1
7	574 18 15-01	SCREW IHSCFTO		1
8	503 22 24-01	LOCK NUT		1
10	574 47 70-03	SCREW IHSCFMO		1
11	503 96 13-01	SCREW		1
12	740 42 06-00	O-RING		1
13	740 42 06-00	O-RING		2
14	503 96 13-01	SCREW		1
15	502 48 15-01	COVER		1
16	505 14 18-02	CYLINDER COVER ASSY		1
17	505 27 10-01	FILTER		1
18	537 38 72-01	SNAP		2




Ref	Part No	Description	Remark	QTY KIT	
1	503 28 34-01	CARBURETTOR	Zama C1Q-EL24, NOT FOR US	1	
2	503 97 43-01	COVER		1	1
3	503 48 05-01	SCREW		2	1
4	537 02 02-01	COVER		1	1
5	537 02 07-01	SCREW		1	1
6	503 48 11-01	PIECE		1	1
7	503 47 96-01	SCREW		1	1
8	537 04 89-01	DIAPHRAGM		1	1,A,B
9	537 02 04-01	GASKET		1	1,A,B
10	537 02 01-01	GASKET		1	1,A,B
11	537 02 00-01	DIAPHRAGM PUMP		1	1,A,B
12	503 53 57-01	STRAINER		1	1,B
13	503 48 01-01	SCREW		1	1
14	503 48 00-01	PIN RETAINING SCREW		1	1,B
15	503 66 59-01	LEVER		1	1,B
16	537 02 03-01	SPRING		1	1,B
17	503 47 97-01	VALVE		1	1,B
18	537 02 08-01	PLUG		1	1,B
19	537 01 25-01	BALL		1	1
20	537 01 26-01	SPRING		1	1
21	537 02 09-01	SHAFT ASSY		1	1
22	537 37 03-01	VALVE		1	1
23	503 48 18-01	SCREW		1	1
24	503 48 19-01	COLLAR		1	1
25	537 04 90-01	LEVER		1	1
26	537 02 10-01	SPRING		1	1
27	503 75 53-01	SCREW		1	1
28	537 01 96-01	SHAFT ASSY		1	1
29	537 01 99-01	VALVE		1	1
30	503 47 92-01	SCREW		1	1
31	537 01 97-01	SPRING		1	1
32	503 47 89-01	COLLAR		1	1
33	537 01 98-01	LEVER		1	1
34	503 47 90-01	SCREW		1	1
35	537 02 06-01	SCREW		1	1
36	537 12 78-01	SCREW		1	1
37	503 97 40-01	WASHER		1	1
38	503 48 08-01	SPRING		1	1
39	537 02 16-01	LIMITER CAP		1	1
40	537 02 16-01	LIMITER CAP		1	1
41,A	531 00 45-52	GASKET KIT		1	
42,B	531 00 45-53	SET		1	

H3 327LS
COVERS

COVER

327 LS, 2009, 2010


Ref	Part No	Description	Remark	QTY KIT
1	505 14 20-01	FILTER COVER		1
2	505 14 22-01	COVER		1
3	503 20 03-16	SCREW IHSCFM	M5x16	4
4	503 21 35-12	SCREW CCRPANT		2
5	502 48 16-01	ARM PROTECTION		1
6	544 84 81-01	HEAT PROTECTOR		1
7	503 21 68-20	SCREW IHSCFT		1
8	503 22 24-01	LOCK NUT		1
10	503 20 03-16	SCREW IHSCFM		1
11	503 96 13-01	SCREW		1
12	740 42 06-00	O-RING		1
13	740 42 06-00	O-RING		1
14	503 96 13-01	SCREW		1
15	502 48 15-01	COVER		1
16	505 14 18-02	CYLINDER COVER ASSY		1
17	505 27 10-01	FILTER		1
18	537 38 72-01	SNAP		2

H4 327LS
COVERS

COVER

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY	KIT
1	505 14 20-01	FILTER COVER		1	
2	505 14 22-01	COVER		1	
3	574 47 70-03	SCREW IHSCFMO	Captive screws	4	16
4	503 21 35-12	SCREW CCRPANT		2	
5	502 48 16-01	ARM PROTECTION		1	
6	544 84 81-02	HEAT PROTECTOR	Captive screws	1	
7	574 18 15-01	SCREW IHSCFTO	Captive screws	1	6
8	503 22 24-01	LOCK NUT		1	
10	574 47 70-03	SCREW IHSCFMO	Captive screws	1	6
11	503 96 13-01	SCREW		1	
12	740 42 06-00	O-RING		1	
13	740 42 06-00	O-RING		1	
14	503 96 13-01	SCREW		1	
15	502 48 15-01	COVER		1	
16	505 14 18-02	CYLINDER COVER ASSY	Captive screws	1	
17	505 27 10-01	FILTER		1	
18	537 38 72-01	SNAP		2	


P 327LS, LX, LDX, RX, RDX, RJX, 323RII
CRANK CASE

CRANKCASE

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT	
1	537 30 96-01	COMPRESSION SLEEVE		1	
2	503 21 68-25	SCREW IHSCFT		1	1
3	503 21 68-25	SCREW IHSCFT		1	1
4	537 04 12-09	CLUTCH COVER		1	
5	537 42 50-01	PROTECTIVE PLATE		1	4
6	503 20 03-16	SCREW IHSCFM	M5x16	1	4
7	537 07 36-01	SPRING		1	
8	503 25 05-01	BALL BEARING		1	4
9	537 33 67-01	CIRCLIP		1	4
10	537 08 52-02	CRANKCASE		1	
11	503 20 03-16	SCREW IHSCFM		1	10
12	537 06 69-01	GASKET CRANKCASE		1	10
13	537 08 85-01	GASKET		1	10
14	537 06 68-01	INSERT CRANKCASE		1	10
15	503 20 03-16	SCREW IHSCFM		1	10
16	503 20 03-16	SCREW IHSCFM		1	10
17	503 21 66-18	SCREW IHSCFT		1	10
18	503 20 03-16	SCREW IHSCFM		1	10
19	503 21 66-18	SCREW IHSCFT		1	10
20	503 20 03-16	SCREW IHSCFM		1	10
21	503 21 77-16	SCREW IHSCFT		1	10
22	503 20 14-12	SCREW IHSCFMO	M5x12	1	10
23	503 20 03-16	SCREW IHSCFM		1	10


Q 327LS, LX, LDX, RX, RDX, RJX, 323RII
CRANK SHAFT



CRANKSHAFT

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT	
1	503 85 24-74	CRANKSHAFT ASSY		1	
2	503 94 02-03	BEARING CAGE		2	1
3	503 94 05-01	CUP		2	1
4	503 71 22-01	BEARING		1	1


N 327LS, LX, LDX, RX, RDX, RJX, 323RII
CYLINDER PISTON & MUFFLER

CYLINDER, PISTON & MUFFLER

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT	
1	537 22 17-04	MUFFLER ASSY	Cat.	1	
2	537 22 18-01	SPARK ARRESTOR SCREEN		1	1
3	537 01 41-01	GASKET		1	
4	502 07 81-01	SCREW EHHFM		3	
5	537 08 51-03	CYLINDER	Ø=34mm	1	
6	503 20 07-35	SCREW IHSCFM		4	5
7	537 40 59-02	PISTON		1	5
8	537 40 62-01	PISTON RING		1	7
9	737 44 08-00	CIRCLIP		1	7
10	503 71 22-01	BEARING		1	7

L 327LS, LX, LDX, RX, RDX, RJX, 323RII
FUEL TANK




FUEL TANK


327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT	
1	506 12 45-01	FUEL TANK ASSY		1	
2	544 32 50-01	FUEL HOSE		1	1
3	537 04 24-01	FUEL HOSE		1	1
4	537 04 24-01	FUEL HOSE		1	1
5	503 73 58-01	BUSHING		2	1
6	504 02 24-01	HOSE CLAMP		1	1
7	503 44 32-01	FILTER		1	1
8	503 93 66-01	PRIMER HOUSING		1	
9	537 18 49-01	O-RING		1	
10	544 88 97-02	TANK CAP		1	
11	503 91 10-01	SUSPENSION		4	

G 327LS, Lx, LDx, RJx THROTTLE CONTROLS



Ref	Part No	Description	Remark	QTY KIT	
1	544 14 36-04	CONTROL		1	
2	537 41 90-01	SWITCH		1	1
3	503 21 66-18	SCREW IH SCT		5	1
4	544 10 02-02	HANDLE HALF		1	1
5	503 87 80-01	THROTTLE LOCKOUT		1	1
6	503 91 81-01	THROTTLE LEVER		1	1
7	503 96 14-01	ABSORBER		1	1
8	544 10 03-02	HANDLE HALF		1	1
9	544 10 08-01	RECOIL SPRING		1	1
10	503 87 79-03	THROTTLE TRIGGER		1	1
11	544 10 17-02	DAMPER		1	1
12	731 23 14-01	HEXAGON NUT		1	1
13	544 11 21-01	RETAINER		1	1
14	503 20 03-20	SCREW IH SCFM		1	1
15	544 10 17-02	DAMPER		1	1
16	502 65 13-01	WIRING		1	1
17	502 53 16-01	SHORT CIRCUIT CABLE		1	1,16
18	544 17 17-03	THROTTLE WIRE ASSY		1	1,16


T Duo Balance
HARNESS

HARNESS

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT	
1	537 27 57-01	HARNESS		1	
1	537 27 57-03	HARNESS	US	1	1
2	503 99 61-01	HARNESS		3	1
3	503 99 61-03	BAND		1	1
4	537 11 35-01	RETAINER		1	1
5	537 28 84-01	FRONT PIECE		1	1
6	537 28 83-01	FRONT PIECE		1	1
7	537 27 59-01	HIP PAD		1	1
8	502 02 28-01	HARNESS		1	1
9	502 02 30-02	HARNESS		1	1,8
10	502 02 38-01	HARNESS		1	1,8
11	502 02 29-02	HARNESS		1	1,8
12	735 31 09-20	HARNESS		1	1,8
13	537 17 54-01	HARNESS		3	1


M 327LS, LX, LDX, RX, RDX, RJX, 323RII
IGNITION & CLUTCH





IGNITION SYSTEM & CLUTCH

327 LS, 2009, 2010


Ref	Part No	Description	Remark	QTY	KIT
1	502 49 36-01	SHORT CIRCUIT CABLE		1	
2	537 43 43-01	SPARK PLUG CAP		1	
3	503 23 51-09	SPARK PLUG	Champion RCJ 6Y	1	
4	544 12 70-01	IGNITION MODULE		1	
5	503 21 66-18	SCREW IHSCT		2	
6	537 23 75-01	CLUTCH DRUM ASSY		1	
7	503 84 29-02	SCREW		2	
8	537 04 67-02	WASHER		1	
9	537 03 22-01	CLUTCH ASSY		1	
10	503 84 28-01	CLUTCH SHOE		2	9
11	503 81 60-01	CLUTCH SPRING		1	9
12	537 04 68-02	WASHER		1	
13	731 71 16-51	HEXAGON NUT FLANGE		1	
14	537 24 96-02	FLYWHEEL		1	
15	501 48 56-01	CONTACT SPRING		1	

B 327LX, RJX
SHAFT & HANDLE

Captive screws




Ref	Part No	Description	Remark	QTY KIT
1	503 99 78-01	HANDLE	RJx	1
1	503 99 78-04	HANDLE	Captive screws	1
2	503 88 88-01	TUBE	L=1483mm Ø=24mm	1
2	540 05 38-01	TUBE DRIVESHAFT ASSY	RJx L=1483mm Ø=24mm France	1
3	725 23 78-51	SCREW EHHM	L, LS. M6X40	1
3	725 23 80-51	SCREW EHHM	Lx, RJxM6X50	1
4	503 87 90-01	KNOB	Lx	1
5	503 23 00-61	WASHER	L, LS	1
6	503 87 19-03	HANDLE		1
6	503 87 19-08	HANDLE	Captive screws	1
7	503 94 03-01	DISTANCE		1
8	503 20 07-16	SCREW IHSCFM	RJx	1
9	503 94 10-01	HOOK	RJx	1
10	731 23 14-01	HEXAGON NUT	RJx	1
11	503 21 68-16	SCREW IH SCT	RJx	3
11	574 18 15-01	SCREW IHSCFTO	Captive screws	3
12	502 19 71-01	SQUARE NUT		1
13	537 23 48-01	DRIVE SHAFT	L=1525mm Ø=7mm	1
14	735 31 12-00	CIRCLIP		1
15	537 23 75-01	CLUTCH DRUM ASSY		1
16	537 29 48-01	LABEL		1
17	503 79 56-01	LABEL		1
18	537 10 10-01	LABEL	RJx	1
19	537 08 55-01	HANDLE	France	1

K5 327LS
STARTER

STARTER

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT	
1	503 87 33-05	BRIDGE		1	
2	735 31 08-20	E-CLIP		2	1
3	503 87 36-01	SPRING		1	1
4	503 87 35-02	STARTER PAWL		2	1
5	505 19 83-01	STARTER ASSY		1	
6	503 21 77-16	SCREW IHST		1	5
7	537 33 23-03	STARTER PULLEY		1	5
8	537 37 93-02	SPACING SLEEVE		2	5
9	505 30 51-25	STARTER CORD		1	5
10	537 00 84-01	STARTER HANDLE		1	5
11	505 14 13-01	STARTER ASSY		1	5
12	537 37 93-02	SPACING SLEEVE		3	5
13	503 20 03-16	SCREW IHSCFM	M5x16	3	
14	503 21 66-18	SCREW IHST		1	
15	503 21 66-18	SCREW IHST		1	
16	503 20 14-12	SCREW IHSCFMO	M5x12	1	
17	537 03 41-01	PROTECTIVE PLATE		1	
18	505 14 16-01	BRACKET		1	
19	503 20 03-16	SCREW IHSCFM		2	
20	503 21 53-16	SCREW ITXSCM		1	
21	537 32 24-10	LABEL		1	

K6 327LS
STARTER

STARTER

327 LS, 2009, 2010

Ref	Part No	Description	Remark	QTY KIT	
1	503 87 33-05	BRIDGE		1	
2	735 31 08-20	E-CLIP		2	1
3	503 87 36-01	SPRING		1	1
4	503 87 35-02	STARTER PAWL		2	1
5	505 19 83-01	STARTER ASSY		1	
6	503 21 88-76	SCREW IHSC T		1	5
7	537 33 23-03	STARTER PULLEY		1	5
8	537 37 93-02	SPACING SLEEVE		2	5
9	505 30 51-25	STARTER CORD		1	5
10	537 00 84-01	STARTER HANDLE		1	5
11	505 14 13-01	STARTER ASSY		1	5
12	537 37 93-02	SPACING SLEEVE		3	5
13	503 20 03-16	SCREW IHSCFM	M5x16	3	
15	503 21 66-18	SCREW IHSC T		2	
16	503 20 14-12	SCREW IHSCFMO	M5x12	1	
17	537 03 41-01	PROTECTIVE PLATE		1	
18	505 14 16-01	BRACKET		1	5
19	574 47 70-03	SCREW IHSCFMO	Captive screws	2	5
20	503 21 53-16	SCREW ITXSCM		1	5
21	537 32 24-10	LABEL		1	
22	537 32 50-03	STARTER PULLEY		1	5
23	503 85 99-01	RECOIL SPRING		1	5