




# SPARE PARTS LIST




BRUSHCUTTERS/CLEARING<sup>®</sup> SAWS

535 LST

**A** 535 LST  
BEVEL GEAR

| Ref | Part No      | Description    | Remark | QTY KIT |    |
|-----|--------------|----------------|--------|---------|----|
| 1   | 537 33 38-02 | BEVEL GEAR     |        | 1       |    |
| 2   | 503 85 63-01 | NUT            |        | 1       | 1  |
| 3   | 537 28 56-01 | SUPPORT FLANGE |        | 1       | 1  |
| 4   | 537 29 26-01 | CUP            |        | 1       | 1  |
| 5   | 537 23 49-01 | DRIVER ASSY    |        | 1       | 1  |
| 6   | 735 31 28-10 | CIRCLIP        |        | 1       | 1  |
| 7   | 503 25 24-01 | BALL BEARING   |        | 1       | 1  |
| 8   | 738 21 98-00 | BALL BEARING   |        | 1       | 1  |
| 9   | 503 20 15-01 | SCREW          |        | 1       | 1  |
| 10  | 503 20 14-12 | SCREW IHSCFMO  |        | 1       | 1  |
| 11  | 503 20 07-25 | SCREW IHSCFM   |        | 1       | 1  |
| 12  | 738 21 99-00 | BALL BEARING   |        | 1       | 1  |
| 13  | 738 21 99-02 | BALL BEARING   |        | 1       | 1  |
| 14  | 735 31 11-00 | CIRCLIP        |        | 1       | 1  |
| 15  | 735 31 25-10 | CIRCLIP        |        | 1       | 1  |
| 16  | 503 20 20-07 | SCREW IHSCM    |        | 1       | 18 |
| 17  | 503 20 14-12 | SCREW IHSCFMO  |        | 1       | 18 |
| 18  | 574 30 69-04 | CLAMP          |        | 1       | 1  |



**B** 535 LST  
SHAFT



3

## SHAFT

535 LST

| Ref | Part No      | Description | Remark | QTY KIT |
|-----|--------------|-------------|--------|---------|
| 1   | 503 88 88-01 | TUBE        |        | 1       |
| 2   | 581 81 51-01 | DRIVE SHAFT |        | 1       |
| 3   | 589 29 51-01 | LABEL       |        | 1       |

The logo for GPL, featuring the letters 'GPL' in a bold, stylized font. A registered trademark symbol (®) is located to the upper right of the 'L'.

**D** 535 LST  
THROTTLE CONTROLS


## THROTTLE CONTROLS

535 LST

| Ref | Part No      | Description         | Remark    | QTY KIT |        |
|-----|--------------|---------------------|-----------|---------|--------|
| 1   | 503 91 81-01 | THROTTLE LEVER      |           | 1       | 15     |
| 2   | 544 10 08-01 | RECOIL SPRING       |           | 1       | 15     |
| 3   | 503 87 80-01 | THROTTLE LOCKOUT    |           | 1       | 15     |
| 4   | 503 87 79-03 | THROTTLE TRIGGER    |           | 1       | 15     |
| 5   | 503 96 14-01 | ABSORBER            |           | 1       | 15     |
| 6   | 537 41 90-01 | SWITCH              |           | 1       | 15     |
| 7   | 503 21 66-18 | SCREW IHSCT         |           | 5       | 15     |
| 8   | 544 23 84-01 | HANDLE HALF         | Hard grip | 1       | 15     |
| 9   | 544 23 85-01 | HANDLE HALF         | Hard grip | 1       | 15     |
| 10  | 590 04 21-01 | DAMPER              |           | 1       | 15     |
| 11  | 731 23 14-01 | HEXAGON NUT         |           | 1       | 15     |
| 12  | 589 63 85-01 | RETAINER            |           | 1       | 15     |
| 13  | 506 68 90-01 | BOLT                |           | 1       | 15     |
| 14  | 590 04 21-01 | DAMPER              |           | 1       | 15     |
| 15  | 544 14 36-08 | CONTROL             |           | 1       |        |
| 16  | 503 87 85-06 | SHORT CIRCUIT CABLE |           | 1       | 15, 18 |
| 17  | 544 17 17-02 | THROTTLE CABLE ASSY |           | 1       | 15, 18 |
| 18  | 544 14 49-01 | WIRING ASSY         |           | 1       | 15     |
| 19  | 725 23 80-51 | SCREW EHHM          |           | 1       |        |
| 20  | 503 87 90-01 | KNOB                |           | 1       |        |
| 21  | 503 23 00-61 | WASHER              |           | 1       |        |
| 22  | 503 87 19-08 | HANDLE              |           | 1       |        |
| 23  | 502 19 71-01 | SQUARE NUT          |           | 1       |        |
| 24  | 503 94 03-01 | DISTANCE            |           | 1       |        |



**E** 535 LST  
FUEL TANK






## FUEL TANK

535 LST

| Ref | Part No      | Description   | Remark | QTY KIT |
|-----|--------------|---------------|--------|---------|
| 1   | 503 93 66-01 | PURGE         |        | 1       |
| 2   | 537 04 24-12 | FUEL HOSE     |        | 1       |
| 3   | 578 97 56-02 | FUEL HOSE     |        | 1       |
| 4   | 537 04 24-12 | FUEL HOSE     |        | 1       |
| 5   | 503 73 58-01 | BUSHING       |        | 2       |
| 6   | 537 18 49-01 | O-RING        |        | 1       |
| 7   | 503 44 32-01 | FUEL FILTER   |        | 1       |
| 8   | 544 32 88-01 | TANK ASSY     |        | 1       |
| 9   | 503 91 10-01 | SUSPENSION    |        | 4       |
| 10  | 590 32 48-01 | TANK CAP ASSY |        | 1       |




**F** 535 LST  
CLUTCH

## CLUTCH

535 LST


| Ref | Part No      | Description           | Remark | QTY KIT |    |
|-----|--------------|-----------------------|--------|---------|----|
| 1   | 544 11 97-01 | COVER                 |        | 1       |    |
| 2   | 503 96 13-01 | SCREW                 |        | 2       |    |
| 4   | 537 31 00-01 | COVER                 |        | 1       |    |
| 5   | 537 32 27-01 | ANTIVIBRATION ELEMENT |        | 1       |    |
| 6   | 725 53 33-55 | SCREW IHSCM           |        | 1       |    |
| 7   | 503 20 03-20 | SCREW IHSCFM          |        | 3       |    |
| 8   | 537 31 01-02 | COMPRESSION SLEEVE    |        | 1       |    |
| 9   | 735 31 14-00 | CIRCLIP               |        | 1       |    |
| 10  | 503 24 07-02 | PARALLEL PIN          |        | 2       | 13 |
| 11  | 738 21 01-04 | BALL BEARING          |        | 1       | 13 |
| 12  | 735 31 28-10 | CIRCLIP               |        | 1       | 13 |
| 13  | 537 30 29-01 | CLUTCH COVER          |        | 1       |    |
| 14  | 589 44 72-01 | CLUTCH DRUM           |        | 1       |    |
| 15  | 503 20 03-20 | SCREW IHSCFM          |        | 3       |    |
| 16  | 537 41 81-01 | SCREW                 |        | 2       |    |
| 17  | 537 41 57-01 | WASHER                |        | 1       |    |
| 18  | 537 42 72-01 | SPRING                |        | 1       | 19 |
| 19  | 537 34 04-01 | CLUTCH                |        | 1       |    |
| 20  | 537 04 68-02 | WASHER                |        | 1       |    |



**G****535 LST  
CYLINDER COVER**

| Ref | Part No      | Description      | Remark                            | QTY KIT |   |
|-----|--------------|------------------|-----------------------------------|---------|---|
| 1   | 544 16 01-03 | CYLINDER COVER   | Spare part incl. Screws<br>Pos. 2 | 1       |   |
| 2   | 573 99 43-04 | SCREW IHSCFMO    | Captive screws                    | 1       | 1 |
| 3   | 503 21 29-10 | SCREW CCRPANT    |                                   | 4       | 1 |
| 4   | 537 42 51-02 | HEAT PROTECTOR   | Spare part incl. Screws<br>Pos. 5 | 1       |   |
| 5   | 574 47 70-03 | SCREW IHSCFMO    | Captive screws                    | 1       | 4 |
| 8   | 503 21 75-72 | SCREW IHSCFT     |                                   | 2       |   |
| 9   | 537 35 72-01 | PROTECTIVE PLATE |                                   | 1       |   |
| 10  | 503 21 75-72 | SCREW IHSCFT     |                                   | 1       |   |
| 11  | 544 02 98-01 | BAR              |                                   | 1       |   |
| 13  | 576 99 86-24 | LABEL            |                                   | 1       |   |
| 14  | 503 21 35-02 | SCREW            |                                   | 2       |   |
| 15  | 502 43 39-01 | ARM PROTECTION   |                                   | 1       |   |




**H** 535 LST  
MUFFLER

## MUFFLER

535 LST

| Ref | Part No      | Description           | Remark | QTY KIT |   |
|-----|--------------|-----------------------|--------|---------|---|
| 1   | 544 11 68-01 | SPARK ARRESTER SCREEN |        | 1       | 3 |
| 2   | 724 12 87-59 | SCREW CRPANM          |        | 1       | 3 |
| 3   | 505 40 86-01 | MUFFLER ASSY          | Cat    | 1       |   |
| 4   | 537 33 31-01 | GASKET                |        | 1       |   |
| 5   | 537 34 08-01 | AIR CONDUCTOR         |        | 1       |   |
| 6   | 503 20 03-20 | SCREW IHSCFM          |        | 1       |   |
| 7   | 503 20 29-63 | SCREW IHSCFM          |        | 2       |   |








| Ref | Part No      | Description      | Remark          | QTY KIT |    |
|-----|--------------|------------------|-----------------|---------|----|
| 1   | 537 37 12-02 | INSULATION WALL  |                 | 1       |    |
| 2   | 537 37 11-01 | SLEEVE           |                 | 1       | 1  |
| 3   | 544 01 91-01 | TUBULAR RIVET    |                 | 1       | 1  |
| 4   | 537 33 43-01 | INLET PIPE       |                 | 1       |    |
| 5   | 537 37 38-03 | TUBULAR RIVET    |                 | 2       | 1  |
| 6   | 503 20 03-16 | SCREW IHSCFM     |                 | 2       |    |
| 7   | 503 49 71-01 | GASKET           |                 | 1       |    |
| 8   | 581 16 75-01 | CARBURETTOR      | (ZAMA C1Q-EL36) | 1       |    |
| 9   | 503 23 10-06 | WASHER           |                 | 1       |    |
| 10  | 503 20 03-20 | SCREW IHSCFM     |                 | 1       |    |
| 11  | 544 02 58-01 | BAR              |                 | 1       | 16 |
| 12  | 537 33 71-01 | CHOKE CONTROL    |                 | 1       | 16 |
| 13  | 503 21 29-06 | SCREW CCRPANT    |                 | 1       | 16 |
| 14  | 537 35 58-01 | LEVER            |                 | 1       | 16 |
| 15  | 544 37 27-01 | SLEEVING BRACKET |                 | 1       |    |
| 16  | 537 31 41-01 | FILTER HOLDER    |                 | 1       |    |
| 17  | 503 21 75-50 | SCREW IHSCFT     |                 | 2       |    |
| 18  | 537 33 72-01 | FILTER           |                 | 1       |    |
| 19  | 537 31 42-01 | FRAME            |                 | 1       |    |
| 20  | 537 31 44-01 | FILTER COVER     |                 | 1       |    |
| 21  | 537 38 72-01 | SNAP LOCKING     |                 | 2       |    |
| 22  | 544 01 47-01 | BELLOWS          |                 | 1       | 16 |
| 23  | 544 01 46-01 | LEVER            |                 | 1       | 16 |
| 24  | 503 21 29-06 | SCREW CCRPANT    |                 | 1       | 16 |
| 25  | 537 34 90-01 | LEVER            |                 | 1       |    |
| 26  | 537 34 13-01 | AIR DUCT         |                 | 1       |    |



**K** 535 LST  
STARTER


## STARTER

535 LST

| Ref | Part No      | Description    | Remark                                | QTY KIT |    |
|-----|--------------|----------------|---------------------------------------|---------|----|
| 1   | 577 22 36-02 | DECAL          |                                       | 1       |    |
| 2   | 503 21 79-20 | SCREW IH SCT   |                                       | 1       | 11 |
| 3   | 503 23 00-80 | WASHER         |                                       | 1       | 11 |
| 4   | 537 32 50-03 | STARTER PULLEY |                                       | 1       | 11 |
| 5   | 503 85 99-01 | RECOIL SPRING  |                                       | 1       | 11 |
| 7   | 505 30 51-25 | STARTER CORD   |                                       | 1       | 11 |
| 8   | 503 54 39-01 | STARTER HANDLE |                                       | 1       | 11 |
| 9   | 544 10 25-02 | STARTER        | Spare part adapted for captive screws | 1       | 11 |
| 10  | 573 99 43-05 | SCREW IH SCFMO | Captive screws                        | 3       |    |
| 11  | 537 21 47-07 | STARTER ASSY   |                                       | 1       |    |
| 12  | 503 87 33-05 | STARTER PAWL   |                                       | 1       |    |
| 13  | 735 31 08-20 | E-CLIP         |                                       | 2       | 12 |
| 14  | 503 87 36-01 | SPRING         |                                       | 1       | 12 |
| 15  | 544 01 14-01 | STARTER PAWL   |                                       | 2       | 12 |




**L** 535 LST  
IGNITION



| Ref | Part No      | Description        | Remark              | QTY KIT |
|-----|--------------|--------------------|---------------------|---------|
| 1   | 503 21 66-18 | SCREW IHSCT        |                     | 2       |
| 2   | 544 12 70-02 | IGNITION MODULE    |                     | 1       |
| 3   | 503 23 51-09 | SPARK PLUG         | CH RCJ6Y (Ø =14 mm) | 1       |
| 4   | 537 24 96-02 | FLYWHEEL           |                     | 1       |
| 5   | 731 71 16-51 | HEXAGON NUT FLANGE |                     | 1       |
| 6   | 587 21 22-01 | CONTACT SPRING     |                     | 1       |




**M** 535 LST  
CYLINDER PISTON

## CYLINDER PISTON

535 LST

| Ref | Part No      | Description    | Remark | QTY KIT |     |
|-----|--------------|----------------|--------|---------|-----|
| 1   | 725 53 33-55 | SCREW IHSCM    |        | 4       | 8   |
| 2   | 503 28 90-54 | PISTON RING    |        | 2       | 6,8 |
| 3   | 581 08 10-02 | PISTON PIN     |        | 1       | 6,8 |
| 4   | 503 41 41-01 | NEEDLE BEARING |        | 1       | 6,8 |
| 5   | 737 44 10-00 | SNAP RING      |        | 2       | 6,8 |
| 6   | 585 99 83-02 | PISTON ASSY    |        | 1       | 8   |
| 7   | 537 33 30-02 | GASKET         |        | 1       |     |
| 8   | 574 36 43-01 | CYLINDER ASSY  |        | 1       |     |


The image shows a large, light gray watermark of the letters "GPL" with a registered trademark symbol (®) to the upper right of the "L".

**N** 535 LST  
CRANK SHAFT



| Ref | Part No      | Description     | Remark | QTY KIT |   |
|-----|--------------|-----------------|--------|---------|---|
| 1   | 503 26 02-02 | SEALING RING    |        | 1       | 8 |
| 2   | 738 21 01-10 | BALL BEARING    |        | 1       | 8 |
| 3   | 537 29 76-01 | CUP             |        | 1       | 8 |
| 4   | 503 41 41-01 | NEEDLE BEARING  |        | 1       | 8 |
| 5   | 537 29 76-01 | CUP             |        | 1       | 8 |
| 6   | 738 21 01-10 | BALL BEARING    |        | 1       | 8 |
| 7   | 503 26 02-02 | SEALING RING    |        | 1       | 8 |
| 8   | 544 03 90-01 | CRANKSHAFT ASSY |        | 1       |   |





**P** 535 LST  
CRANKCASE

## CRANKCASE

535 LST

| Ref | Part No      | Description    | Remark | QTY | KIT |
|-----|--------------|----------------|--------|-----|-----|
| 1   | 503 20 02-30 | SCREW IHSCFM   |        | 4   | 9   |
| 2   | 503 26 02-02 | SEALING RING   |        | 1   | 9   |
| 3   | 738 21 01-10 | BALL BEARING   |        | 1   | 9   |
| 4   | 593 80 60-01 | GUIDE BUSHING  |        | 2   | 9   |
| 5   | 593 77 76-01 | GASKET         |        | 1   | 9   |
| 6   | 537 32 42-01 | INSERT         |        | 1   | 9   |
| 7   | 738 21 01-10 | BALL BEARING   |        | 1   | 9   |
| 8   | 503 26 02-02 | SEALING RING   |        | 1   | 9   |
| 9   | 544 03 89-01 | CRANKCASE ASSY |        | 1   |     |




**R1** 535 LST  
ACCESSORIES

## ACCESSORIES

535 LST

| Ref | Part No      | Description       | Remark | QTY KIT |    |
|-----|--------------|-------------------|--------|---------|----|
| 8   | 588 11 79-01 | COMBINATION GUARD |        | 1       |    |
| 9   | 503 79 88-01 | BLADE             |        | 1       | 8  |
| 10  | 576 27 56-01 | SCREW ITXSCFT     |        | 1       | 8  |
| 11  | 501 13 67-03 | GUARD             |        | 1       |    |
| 12  | 521 00 06-01 | NUT               |        | 2       | 11 |
| 13  | 574 39 56-01 | BLADE             |        | 1       | 11 |
| 14  | 502 84 39-01 | SCREW             |        | 2       | 11 |

The logo for GPL, consisting of the letters 'GPL' in a large, bold, sans-serif font. A registered trademark symbol (®) is located to the upper right of the 'L'.


**R2** 535 LST  
ACCESSORIES

## ACCESSORIES

535 LST

| Ref | Part No      | Description        | Remark        | QTY KIT |
|-----|--------------|--------------------|---------------|---------|
| 1   | 501 19 22-01 | TOOL               |               | 1       |
| 2   | 531 00 92-48 | FILTER OIL         | Oil Airfilter | 1       |
| 3   | 503 97 64-01 | GREASE             |               | 1       |
| 4   | 502 28 59-01 | STOP               |               | 1       |
| 5   | 503 80 17-01 | GREASE             |               | 1       |
| 6   | 537 36 21-02 | COMBINATION WRENCH |               | 1       |
| 7   | 503 94 10-01 | HOOK               |               | 1       |
| 8   | 503 20 07-16 | SCREW IHSCFM       |               | 1       |
| 9   | 731 23 14-01 | HEXAGON NUT        |               | 1       |
| 10  | 537 21 62-01 | HARNESS            |               | 1       |
| 10  | 537 21 62-02 | HARNESS            | USA           | 1       |








| Ref | Part No      | Description | Remark    | QTY KIT |
|-----|--------------|-------------|-----------|---------|
| 1   | 576 79 68-01 | SHORT BLOCK | Assembled | 1       |




## CARBURETOR DETAILS

## Zama C1Q-EL36D



| Ref | Part No      | Description         | Remark | QTY KIT |       |
|-----|--------------|---------------------|--------|---------|-------|
| 1   | 581 16 75-01 | CARBURETTOR         |        | 1       |       |
| 2   | 503 47 92-01 | SCREW               |        | 1       | 1     |
| 3   | 537 41 72-01 | VALVE               |        | 1       | 1     |
| 4   | 544 37 24-01 | SPRING              |        | 1       | 1     |
| 5   | 503 48 05-01 | SCREW               |        | 2       | 1     |
| 6   | 503 97 43-01 | COVER               |        | 1       | 1     |
| 7   | 537 04 89-01 | DIAPHRAGM           |        | 1       | 1, 43 |
| 8   | 537 02 04-01 | GASKET              |        | 1       | 1, 43 |
| 9   | 503 53 56-01 | PLUG WELCH          |        | 1       | 1     |
| 10  | 581 89 95-01 | MAIN NOZZLE         |        | 1       | 1     |
| 11  | 503 48 01-01 | SCREW               |        | 1       | 1     |
| 12  | 503 48 00-01 | PIN RETAINING SCREW |        | 1       | 1     |
| 13  | 503 66 59-01 | LEVER               |        | 1       | 1     |
| 14  | 503 47 97-01 | VALVE               |        | 1       | 1     |
| 15  | 503 47 81-01 | SPRING              |        | 1       | 1     |
| 16  | 544 37 22-01 | SHAFT ASSY          |        | 1       | 1     |
| 17  | 537 37 03-01 | VALVE               |        | 1       | 1     |
| 18  | 503 48 18-01 | SCREW               |        | 1       | 1     |
| 19  | 544 37 26-01 | SPRING              |        | 1       | 1     |
| 20  | 544 37 25-01 | LEVER               |        | 1       | 1     |
| 21  | 544 42 70-01 | COLLAR              |        | 1       | 1     |
| 23  | 537 01 26-01 | SPRING              |        | 1       | 1     |
| 24  | 537 01 25-01 | BALL                |        | 1       | 1     |
| 25  | 503 48 13-01 | STRAINER            |        | 1       | 1     |
| 26  | 544 37 23-01 | LEVER               |        | 1       | 1     |
| 27  | 503 47 90-01 | SCREW               |        | 1       | 1     |
| 28  | 537 41 69-01 | SCREW               |        | 1       | 1     |
| 29  | 537 41 70-01 | LIMITER CAP         |        | 2       | 1     |
| 30  | 581 89 93-01 | SCREW               |        | 1       | 1     |
| 31  | 537 38 52-01 | CLIP                |        | 1       | 1     |
| 32  | 537 38 50-01 | CLIP                |        | 1       | 1     |
| 33  | 537 41 73-01 | LEVER               |        | 1       | 1     |
| 34  | 576 74 66-01 | SPRING              |        | 1       | 1     |
| 35  | 537 41 74-01 | LEVER               |        | 1       | 1     |
| 36  | 502 07 84-01 | SCREW               |        | 1       | 1     |
| 37  | 537 02 00-01 | DIAPHRAGM PUMP      |        | 1       | 1, 43 |
| 38  | 537 02 01-01 | GASKET              |        | 1       | 1, 43 |
| 39  | 537 41 68-01 | COVER               |        | 1       | 1     |
| 40  | 537 02 07-01 | SCREW               |        | 1       | 1     |
| 41  | 503 48 11-01 | PIECE               |        | 1       | 1     |
| 42  | 503 47 96-01 | SCREW               |        | 1       | 1     |
| 43  | 531 00 45-52 | GASKET KIT          |        | 1       |       |
| 44  | 544 37 21-01 | SHAFT ASSY          |        | 1       | 1     |



## CARBURETOR DETAILS

535 LST

| Ref | Part No      | Description         | Remark | QTY KIT |       |
|-----|--------------|---------------------|--------|---------|-------|
| 1   | 581 16 75-01 | CARBURETTOR         |        | 1       |       |
| 2   | 503 47 92-01 | SCREW               |        | 1       | 1     |
| 3   | 537 41 72-01 | VALVE               |        | 1       | 1     |
| 4   | 544 37 24-01 | SPRING              |        | 1       | 1     |
| 5   | 503 48 05-01 | SCREW               |        | 2       | 1     |
| 6   | 503 97 43-01 | COVER               |        | 1       | 1     |
| 7   | 537 04 89-01 | DIAPHRAGM           |        | 1       | 1, 43 |
| 8   | 537 02 04-01 | GASKET              |        | 1       | 1, 43 |
| 9   | 503 53 56-01 | PLUG WELCH          |        | 1       | 1     |
| 10  | 581 89 95-01 | MAIN NOZZLE         |        | 1       | 1     |
| 11  | 503 48 01-01 | SCREW               |        | 1       | 1     |
| 12  | 503 48 00-01 | PIN RETAINING SCREW |        | 1       | 1     |
| 13  | 503 66 59-01 | LEVER               |        | 1       | 1     |
| 14  | 503 47 97-01 | VALVE               |        | 1       | 1     |
| 15  | 503 47 81-01 | SPRING              |        | 1       | 1     |
| 16  | 544 37 22-01 | SHAFT ASSY          |        | 1       | 1     |
| 17  | 537 37 03-01 | VALVE               |        | 1       | 1     |
| 18  | 503 48 18-01 | SCREW               |        | 1       | 1     |
| 19  | 544 37 26-01 | SPRING              |        | 1       | 1     |
| 20  | 544 37 25-01 | LEVER               |        | 1       | 1     |
| 21  | 544 42 70-01 | COLLAR              |        | 1       | 1     |
| 23  | 537 01 26-01 | SPRING              |        | 1       | 1     |
| 24  | 537 01 25-01 | BALL                |        | 1       | 1     |
| 25  | 503 48 13-01 | STRAINER            |        | 1       | 1     |
| 26  | 544 37 23-01 | LEVER               |        | 1       | 1     |
| 27  | 503 47 90-01 | SCREW               |        | 1       | 1     |
| 28  | 537 41 69-01 | SCREW               |        | 1       | 1     |
| 29  | 537 41 70-01 | LIMITER CAP         |        | 2       | 1     |
| 30  | 581 89 93-01 | SCREW               |        | 1       | 1     |
| 31  | 537 38 52-01 | CLIP                |        | 1       | 1     |
| 32  | 537 38 50-01 | CLIP                |        | 1       | 1     |
| 33  | 537 41 73-01 | LEVER               |        | 1       | 1     |
| 34  | 576 74 66-01 | SPRING              |        | 1       | 1     |
| 35  | 537 41 74-01 | LEVER               |        | 1       | 1     |
| 36  | 502 07 84-01 | SCREW               |        | 1       | 1     |
| 37  | 537 02 00-01 | DIAPHRAGM PUMP      |        | 1       | 1, 43 |
| 38  | 537 02 01-01 | GASKET              |        | 1       | 1, 43 |
| 39  | 537 41 68-01 | COVER               |        | 1       | 1     |
| 40  | 537 02 07-01 | SCREW               |        | 1       | 1     |
| 41  | 503 48 11-01 | PIECE               |        | 1       | 1     |
| 42  | 503 47 96-01 | SCREW               |        | 1       | 1     |
| 43  | 531 00 45-52 | GASKET KIT          |        | 1       |       |
| 44  | 544 37 21-01 | SHAFT ASSY          |        | 1       | 1     |