

# BP 2040 C

**Spare parts**

**Ersatzteile**



**Pièces détachées**

**Reserve onderdelen**


**Repuestos**

**Reservdelar**

GPL®


**A****\*compl 503 73 87-04****B**

**C**




**D**

\*compl 503 69 46-01




**E**









**F**

\*compl 502 21 28-04




**G**



**H****\*compl 503 92 22-04****J****\*compl 503 90 47-02****K****compl 502 21 92-04****L****\*compl 503 79 06-01****M****\*compl 502 21 95-01****Jonsered GR**


**N**

compl 503 28 15-16 Walbro WT 500B



**P**

**Accessories**  
**Zubehöre**  
**Accessoires**  
**Accesorios**  
**Tillbehör**



| Part number  | Square | Note | Part number  | Square | Note | Part number  | Square | Note | Part number | Square | Note |
|--------------|--------|------|--------------|--------|------|--------------|--------|------|-------------|--------|------|
| 501 27 82-01 | H      |      | 503 68 64-02 | D      |      | 503 91 34-01 | F      |      |             |        |      |
| 501 46 69-01 | N      |      | 503 69 46-01 | D      |      | 503 91 39-01 | N      |      |             |        |      |
| 501 46 84-01 | N      |      | 503 69 63-01 | K      |      | 503 91 40-01 | N      |      |             |        |      |
| 501 46 85-01 | N      |      | 503 69 67-01 | K      |      | 503 91 51-01 | N      |      |             |        |      |
| 501 46 87-01 | N      |      | 503 70 07-01 | K      |      | 503 91 54-01 | N      |      |             |        |      |
| 501 48 54-02 | L      |      | 503 70 29-02 | K      |      | 503 91 57-01 | N      |      |             |        |      |
| 501 60 02-02 | P      |      | 503 70 55-01 | K      |      | 503 91 58-01 | N      |      |             |        |      |
| 501 66 61-01 | N      |      | 503 70 80-01 | B      |      | 503 92 22-04 | H      |      |             |        |      |
| 501 66 78-01 | N      |      | 503 71 48-01 | K      |      | 503 92 23-01 | N      |      |             |        |      |
| 501 76 83-24 | H      |      | 503 71 54-01 | B      |      | 503 93 66-01 | G      |      |             |        |      |
|              |        |      |              |        |      |              |        |      |             |        |      |
| 502 03 55-05 | P      |      | 503 71 82-01 | A      |      | 503 93 86-01 | C      |      |             |        |      |
| 502 10 30-01 | N      |      | 503 72 14-04 | A      |      | 503 97 37-08 | C      |      |             |        |      |
| 502 10 31-01 | N      |      | 503 72 15-02 | A      |      | 503 99 44-01 | N      |      |             |        |      |
| 502 11 46-02 | P      |      | 503 72 29-02 | B      |      | 503 99 46-01 | N      |      |             |        |      |
| 502 18 94-02 | E      |      | 503 72 77-01 | B      |      | 503 99 47-01 | N      |      |             |        |      |
| 502 19 71-01 | B      |      | 503 73 58-01 | H      |      | 503 99 48-01 | N      |      |             |        |      |
| 502 19 84-01 | G      |      | 503 73 84-01 | P      |      | 504 13 08-07 | N      |      |             |        |      |
| 502 19 86-02 | G      |      | 503 73 85-02 | B      |      | 504 13 09-06 | N      |      |             |        |      |
| 502 20 06-01 | M      |      | 503 73 86-02 | P      |      | 504 21 00-49 | N      |      |             |        |      |
| 502 20 65-01 | G      |      | 503 73 86-04 | P      |      | 504 21 00-50 | N      |      |             |        |      |
|              |        |      |              |        |      |              |        |      |             |        |      |
| 502 20 83-02 | G      |      | 503 73 87-04 | A      |      | 504 98 00-20 | P      |      |             |        |      |
| 502 20 84-01 | G      |      | 503 73 88-01 | H      |      | 505 30 51-25 | M      |      |             |        |      |
| 502 20 88-01 | D      |      | 503 73 94-01 | H      |      | 505 31 67-17 | N      |      |             |        |      |
| 502 21 23-01 | G      |      | 503 73 98-01 | H      |      | 505 31 67-45 | N      |      |             |        |      |
| 502 21 28-04 | F      |      | 503 73 99-01 | H      |      | 505 31 67-54 | N      |      |             |        |      |
| 502 21 33-01 | N      |      | 503 74 00-01 | E      |      | 505 31 67-82 | N      |      |             |        |      |
| 502 21 34-01 | N      |      | 503 74 29-01 | P      |      | 505 52 01-10 | N      |      |             |        |      |
| 502 21 35-01 | N      |      | 503 74 32-02 | A      |      | 505 52 01-25 | N      |      |             |        |      |
| 502 21 37-01 | N      |      | 503 74 33-02 | A      |      | 505 52 01-27 | N      |      |             |        |      |
| 502 21 57-01 | E      |      | 503 74 34-01 | A      |      | 506 02 81-01 | N      |      |             |        |      |
|              |        |      |              |        |      |              |        |      |             |        |      |
| 502 21 58-01 | P      |      | 503 74 40-03 | P      |      | 530 03 51-73 | N      |      |             |        |      |
| 502 21 60-01 | P      |      | 503 74 50-06 | P      |      | 530 03 73-57 | M      |      |             |        |      |
| 502 21 83-04 | M      |      | 503 74 53-01 | P      |      | 537 02 48-01 | G      |      |             |        |      |
| 502 21 85-01 | M      |      | 503 75 34-01 | K      |      | 537 02 87-01 | C      |      |             |        |      |
| 502 21 92-04 | K      |      | 503 75 62-01 | P      |      | 537 02 88-01 | G      |      |             |        |      |
| 502 21 93-01 | B      |      | 503 75 63-01 | P      |      | 537 04 24-02 | G      |      |             |        |      |
| 502 21 95-01 | M      |      | 503 75 64-01 | P      |      | 537 04 24-03 | GH     |      |             |        |      |
| 502 21 98-23 | M      |      | 503 75 65-01 | E      |      | 537 05 27-02 | GN     |      |             |        |      |
| 502 28 59-01 | P      |      | 503 75 76-01 | H      |      | 725 23 79-51 | B      |      |             |        |      |
| 503 10 47-01 | N      |      | 503 76 19-02 | B      |      | 725 23 84-85 | B      |      |             |        |      |
|              |        |      |              |        |      |              |        |      |             |        |      |
| 503 10 87-01 | N      |      | 503 76 47-01 | B      |      | 725 53 29-55 | A      |      |             |        |      |
| 503 11 70-01 | N      |      | 503 76 68-02 | B      |      | 725 53 87-55 | H      |      |             |        |      |
| 503 16 13-02 | E      |      | 503 77 53-01 | M      |      | 725 54 55-55 | H      |      |             |        |      |
| 503 20 02-10 | B      |      | 503 77 63-01 | P      |      | 731 23 14-01 | G      |      |             |        |      |
| 503 20 02-12 | H      |      | 503 77 99-01 | B      |      | 731 23 14-05 | A      |      |             |        |      |
| 503 20 02-16 | P      |      | 503 78 02-04 | B      |      | 731 71 14-51 | G      |      |             |        |      |
| 503 20 02-20 | EK     |      | 503 78 57-01 | B      |      | 735 31 11-00 | K      |      |             |        |      |
| 503 20 02-25 | BK     |      | 503 79 05-02 | L      |      | 735 31 25-10 | K      |      |             |        |      |
| 503 20 25-16 | L      |      | 503 79 06-01 | L      |      | 735 31 31-10 | K      |      |             |        |      |
| 503 20 29-63 | J      |      | 503 79 09-01 | B      |      | 737 44 10-00 | D      |      |             |        |      |
|              |        |      |              |        |      |              |        |      |             |        |      |
| 503 21 06-25 | EM     |      | 503 79 41-01 | A      |      | 738 21 01-04 | H      |      |             |        |      |
| 503 21 07-16 | P      |      | 503 79 88-01 | P      |      | 738 21 98-04 | B      |      |             |        |      |
| 503 21 07-22 | A      |      | 503 80 31-01 | P      |      | 738 21 99-00 | K      |      |             |        |      |
| 503 21 28-10 | B      |      | 503 81 24-01 | L      |      | 738 22 01-19 | K      |      |             |        |      |
| 503 21 29-06 | M      |      | 503 81 29-01 | L      |      | 738 22 01-25 | F      |      |             |        |      |
| 503 21 47-27 | C      |      | 503 82 01-02 | A      |      |              |        |      |             |        |      |
| 503 21 77-16 | M      |      | 503 82 80-04 | H      |      |              |        |      |             |        |      |
| 503 22 10-11 | L      |      | 503 84 32-01 | L      |      |              |        |      |             |        |      |
| 503 22 23-02 | H      |      | 503 85 32-01 | K      |      |              |        |      |             |        |      |
| 503 22 72-01 | H      |      | 503 85 84-01 | P      |      |              |        |      |             |        |      |
|              |        |      |              |        |      |              |        |      |             |        |      |
| 503 23 00-35 | M      |      | 503 85 85-01 | P      |      |              |        |      |             |        |      |
| 503 23 01-01 | EHL    |      | 503 86 43-01 | N      |      |              |        |      |             |        |      |
| 503 23 51-08 | D      |      | 503 88 96-02 | B      |      |              |        |      |             |        |      |
| 503 24 44-01 | L      |      | 503 89 01-01 | P      |      |              |        |      |             |        |      |
| 503 28 90-01 | D      |      | 503 89 67-01 | N      |      |              |        |      |             |        |      |
| 503 41 41-01 | DF     |      | 503 90 46-02 | J      |      |              |        |      |             |        |      |
| 503 44 32-01 | H      |      | 503 90 47-02 | J      |      |              |        |      |             |        |      |
| 503 52 12-04 | E      |      | 503 90 67-01 | F      |      |              |        |      |             |        |      |
| 503 52 42-01 | N      |      | 503 91 07-01 | F      |      |              |        |      |             |        |      |
| 503 57 42-01 | N      |      | 503 91 25-01 | J      |      |              |        |      |             |        |      |