



GT2123

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar

GPL®

A GT2123
HANDLE & CONTROLS



Position	Article	Quantity	Notes	Kit
1	575 68 24-01	1		
2	523 09 81-01	4		
3	575 68 25-01	1		1
4	575 67 97-01	1		1
5	575 68 04-01	1		1
6	523 12 15-01	1		1
7	575 68 18-01	1		1
8	575 68 02-01	1		
9	575 68 32-01	1		
10	544 33 08-01	1		
11	575 68 14-01	1		
12	575 68 29-01	1		
13	575 68 30-01	1		
14	575 68 31-01	1		
15	575 68 27-01	1		
16	575 68 28-01	1		15
17	575 37 38-01	4		15
18	575 68 17-01	1		15
19	575 36 43-01	4		15
20	544 33 08-01	1		
21	575 68 05-01	1		



B

GT2123 ACCESSORIES



22


23

2

Position	Article	Quantity	Notes	Kit
1	575 68 06-01	1		
2	575 68 35-01	1		
3	575 68 08-01	1		1
4	575 68 10-01	2		1
5	575 68 11-01	1		1
6	575 68 12-01	1		1
7	576 13 56-01	1		1
8	575 68 13-01	1		1
9	576 13 57-01	1		1
10	575 68 01-01	1		1
11	575 68 02-01	1		1
12	575 68 07-01	1		1
13	576 13 58-01	1		1
14	575 68 26-01	1		
15	575 67 95-01	2		14
16	575 36 44-01	2		14
17	575 68 15-01	1		14
18	576 13 59-01	1		14
19	575 68 16-01	1		14
20	575 68 03-01	1		14
21	575 68 16-01	1		
22	523 11 17-01	1		
23	523 11 18-01	1		




C GT2123 ENGINE



Position	Article	Quantity	Notes	Kit
1	523 12 23-01	2		
2	575 36 68-01	1		
3	575 36 69-01	1		
4	544 29 55-01	2		
5	575 36 70-01	1		
6	575 36 71-01	1		
7	544 29 39-01	2		
8	544 29 20-01	2		
9	575 36 73-01	1		
10	544 29 22-01	1		
11	575 37 05-01	2		
12	575 37 06-01	1		
13	575 36 74-01	2		
14	575 36 75-01	1		
15	575 36 78-01	1		
16	575 68 37-01	1		
17	575 68 36-01	1		
18	501 38 28-07	1		
19	575 36 80-01	1		
20	575 36 81-01	2		
21	575 36 82-01	1		
22	575 36 83-01	1		
23	575 36 55-01	1		
24	523 09 98-01	3		
25	575 39 76-01	1		
26	575 36 85-01	1		
27	575 36 86-01	1		
28	575 36 87-01	1		
29	575 36 88-01	1		
30	575 36 89-01	2		
31	575 36 90-01	1		
32	575 36 91-01	1		
33	575 36 92-01	2		32
34	575 36 93-01	1		32
35	575 36 94-01	2		
36	575 36 95-01	2		
37	575 36 96-01	2		
38	575 36 97-01	1		
39	544 29 19-01	4		
40	575 36 76-01	3		
41	575 37 04-01	1		
42	575 36 98-01	1		
43	575 36 99-01	1		42
44	575 37 00-01	1		42
45	575 37 01-01	1		42,44
46	544 29 66-01	1		42,44
47	544 29 57-01	1		42,44
48	575 37 02-01	1		42,44,47
49	575 37 03-01	1		42,44,49
50	523 10 32-01	1		42,44,50
51	523 10 34-01	1		42,51
52	575 37 07-01	1		
53	575 37 08-01	1		52
54	575 37 09-01	1		52,53
55	575 37 10-01	1		52,53
56	575 37 11-01	1		52,53
57	575 37 12-01	1		52,53
58	575 37 13-01	1		52,53
59	575 37 14-01	1		52,53
60	575 37 15-01	1		52,53,59
61	575 37 16-01	1		52,53,59
62	575 37 17-01	1		52

D GT2123
CARBURETOR & FUEL TANK



Position	Article	Quantity	Notes	Kit
1	575 37 18-01	1		
2	575 37 21-01	1		1
3	575 37 24-01	1		1
4	575 37 26-01	1		1
5	575 37 25-01	1		1
6	575 37 23-01	1		1
7	575 37 22-01	1		1
8	523 10 70-01	1		1
9	575 37 20-01	1		1
10	575 37 19-01	1		1
11	523 10 73-01	1		1
12	523 10 76-01	1		1
13	523 10 78-01	1		1
14	575 37 28-01	2		1
15	575 37 27-01	4		1
16	575 37 29-01	1		
17	575 37 35-01	1		
18	575 37 33-01	1		
19	575 37 42-01	1		18
20	575 37 34-01	1		18
21	575 37 41-01	1		18
22	575 37 40-01	2		
23	575 37 44-01	1		
24	575 37 45-01	1		23
25	575 37 46-01	1		23
26	575 37 47-01	1		23,25
27	575 37 48-01	1		23
28	575 37 49-01	1		23
29	575 37 50-01	1		23,28
30	575 37 51-01	1		23,28,29
31	575 37 52-01	1		23,28,29
32	575 37 53-01	1		23,28,29
33	575 37 54-01	1		23,28,29
34	523 11 08-01	1		23,28,29
35	575 37 55-01	2		
36	575 37 56-01	1		
37	523 11 08-01	1		