

GT2126

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

GPL®




A

GT2126

Pos.		Part No.	Description	Qty.	Notes
1		530 15 05-61	Assy - Cable	1	Wire Harness
2		545 07 20-01	Trigger	1	
3		545 06 20-03	Housing - Throttle	1	Right Hand
4		530 01 64-48	Screw	2	
5		545 00 75-08	Flexshaft	1	
6		530 01 64-49	Screw	3	
7		530 01 64-54	Spring - Trigger	1	
8		545 08 10-10	Kit - Driveshaft	1	
9		530 05 91-85	Clamp - Handle	1	
10		530 01 61-52	Wingnut	1	
11		545 07 18-01	Housing - Throttle	1	Left Hand
12		545 03 06-01	Kit - Switch	1	
13		545 07 42-01	Handle - Assist	1	
14		530 01 58-20	Bolt	1	
15		545 00 60-49	Kit - Shield	1	Incl.16,17,18,19
16		530 05 22-87	Limiter - Line	1	
17		530 01 58-14	Screw	2	
18		530 01 58-20	Bolt	1	
19		530 01 51-97	Nut	1	
20		545 01 74-03	Dust Cup	1	

The image shows a large, light gray watermark logo for 'GPL' with a registered trademark symbol (®) to the upper right of the 'L'. The logo is centered horizontally and vertically within the lower half of the page.



Pos.		Part No.	Description	Qty.	Notes
1		530 15 02-53	Filter	1	
2		530 01 61-01	Nut - Carb. Screw	2	
3		545 07 17-01	Air Box	1	
4		530 05 78-44	Lever - Choke	1	
5		545 05 04-02	Kit - Carb. Gasket	1	Incl.7,63
6		530 03 55-96	Adaptor - Carburettor	1	
7		545 03 01-01	Kit - Gasket	1	Foam.
8		530 01 64-00	Bolt	2	
9		545 00 10-01	Cylinder	1	
10		952 03 02-01	Spark plugg	1	RCJ-8Y
11		545 05 04-03	Kit - Crankshaft Seal	2	
12		530 01 64-75	Whaser - Starter	1	
13		530 01 64-50	Spring - Starter Cup	1	
14		545 10 23-02	Assy - Starter Cup	1	New part
15		530 05 98-00	Coupling - Starter	1	
16		530 09 56-46	Assy - Fuel Filter	1	
17		545 03 02-01	Kit - Fuel Line	1	
18		545 07 31-01	Assy - Cap	1	Incl.19 , w/ret.
19		530 01 92-93	O-ring - Fuel Tank	1	
20		545 07 30-01	Assy - Fuel Tank	1	Incl.16,17,18,19
21		545 06 52-01	Shroud - Rear	1	
22		530 01 64-48	Screw	4	
23		545 02 99-01	Kit - Rope	1	
24		545 04 32-01	Handle - Starter	1	
25		530 01 64-26	Screw	2	
26		530 01 64-49	Screw	1	
27		545 10 44-01	Starter Hsg	1	With eyelet.
28		545 02 98-01	Kit - Starter Spring	1	
29		545 02 97-01	Kit - Starter Pulley	1	
30		530 01 64-68	Screw	1	
31		545 10 27-01	Assy - Starter Hsg.	1	Incl.23,24,27,28,29,30
32		545 07 16-01	Plate - Wear	1	
33		530 05 97-80	Isolator - Tank	3	
34		530 05 89-82	Bolt - Muffler	2	
35		530 01 54-96	Screw	4	
36		530 15 04-40	Shield - Heat	1	
37		530 01 64-49	Screw	5	
38		545 06 54-01	Guard - Muffler	1	
39		545 03 05-01	Kit - Spark Arrestor	1	Incl.35
40		545 05 75-02	Assy - Muffler	1	New part
41		530 05 78-48	Gasket - Paper Metal	1	
42		530 01 58-97	Screw	4	
43		545 04 67-02	Module	1	
44		530 03 92-27	Assy - Leadwire	1	
45		530 01 64-56	Screw	2	
46		530 01 60-30	Washer	1	
47		530 09 41-89	Washer - Clutch	1	
48		530 01 64-69	Screw	1	
49		530 01 64-70	Screw	1	
50		530 40 30-94	Nut	1	
51		530 01 64-56	Screw	4	
52		545 07 29-01	Assy - Fan Housing	1	
53		545 10 68-01	Assy - Clutch Drum	1	New part
54		545 05 04-05	Kit - Clutch Assy.	1	
55		530 05 78-52	Spacer	1	
56		530 03 92-42	Flywheel	1	
57		545 05 46-01	Crankcase	1	
58		545 01 34-01	Bearing	2	
59		545 03 00-01	Kit - Crankshaft	1	
60		530 01 51-62	Retainer - Piston Pin	2	
61		530 01 92-83	Ring - Piston	1	
62		545 03 03-01	Kit - Piston	1	Incl.60,61
63		545 03 01-01	Kit - Gasket	1	Adaptor seal.
64		530 01 58-97	Screw	2	

B

GT2126

Pos.		Part No.	Description	Qty.	Notes
65		545 00 60-35	Kit - Carburettor	1	New part Incl.4,5
66		545 07 19-01	Cover - Air Box	1	
67		545 07 22-01	Assy - Knob	1	
68		545 03 01-01	Kit - Gasket	1	Incl.5,7,11,19,41,63

The logo for GPL (Grip Limited) is displayed in a large, light gray, sans-serif font. The letters 'GPL' are bold and stylized, with a registered trademark symbol (®) to the upper right of the 'L'.