

GT21 L

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar


GPL®

MODELL GT21L




WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



KEY NO.	PART NO.	DESCRIPTION
1	530 09 51-76	Drive Shaft
2	530 09 46-73	Handle
3	530 04 73-07	Lead Wire Ass'y.
4	530 40 20-27	Throttle Lever
5	530 40 20-25	Throttle Housing (Right)
6	530 40 20-28	Throttle Lock
7	530 03 76-92	Switch
8	530 09 47-42	Clamp-Handle
9	530 01 58-20	Bolt-Shield
10	530 01 61-18	Nut-Shield
11	530 01 58-86	Screw-Line Limiter/ Throttle Housing
12	530 09 54-29	Line Limiter

KEY NO.	PART NO.	DESCRIPTION
13	530 06 96-66	Shield Kit Ass'y. (Incl. 11 & 12)
14	530 01 56-10	Nut-Handle
15	502 71 36-01	Hex Wrench
16	530 40 20-26	Throttle Housing (Left)
17	530 06 92-52	T-Handle Kit
18	530 09 53-06	Drive Shaft Hsg.
19	530 09 45-43	Dust Cup
20	952 71 55-40	Cutting Head Ass'y. (Incl. 21-25)
21	530 09 48-78	Hub Ass'y.
22	530 09 48-30	Spring
23	530 09 48-27	Release Button
24	952 71 55-44	Spool w/Line
25	530 09 48-28	Cover




MODELL GT21L

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	530 02 93-95	Starter Spring	40	530 03 73-26	Choke Plate
2	530 01 57-75	Screw	41	530 03 81-02	Choke Shutter
3	530 02 75-23	Retainer	42	530 01 52-54	Wave Washer
4	530 01 59-34	Screw	43	530 01 58-52	Choke Spacer
5	530 02 75-69	Starter Handle	44	530 01 58-87	Screw
6	530 01 58-10	Scrdrw	45	530 03 74-13	Filter Plate
7	530 01 91-85	Gasket-Carb/Cylin.	46	530 03 73-31	Air Filter Foam
8	503 23 50-08	Spark Plug	47	530 03 72-92	Air Filter Cover
9	530 01 91-94	Gasket-Carb. Adapt.	48	530 01 59-66	Screw
10	530 01 59-45	Retain. Ring C'case	49	530 03 67-44	Throttle Cable Ass'y.
11	530 01 56-75	Screw-Muffler Guard	50	530 01 58-43	Screw
12	530 03 70-45	Muffler Guard	51	530 02 61-19	Check Valve
13	530 03 91-49	Flywheel Ass'y.	52	530 02 97-17	Element
14	530 03 91-63	Ignition Module	53	530 02 96-96	Retainer
15	530 03 61-45	Spacer-Ignition Mod.	54	530 06 92-47	Fuel Line-Tnk./Carb.
16	530 01 59-54	Screw	55	530 01 43-47	Fuel Cap Assty.
17	530 01 58-28	Washer	56	530 01 43-62	Fuel Pickup Assty.
18	530 02 79-53	Drive Coupling	57	530 06 96-25	Engine Gasket Kit
19	530 01 45-32	Crankshaft Ass'y.	59	530 03 76-92	On/Off Switch
20	530 06 96-15	Connecting Rod Assty.	60	530 01 59-53	Screw
21	530 03 64-04	Piston Ring	61	530 01 60-72	Screw
22	530 01 48-61	Crankcase Ass'y.	62	530 01 57-68	Locknut
23	530 03 21-25	Inner Bearing	63	530 04 74-91	Fan Hsg/Shroud Ass'y.
24	530 03 21-24	Outer Bearing	64	530 06 92-32	Rope Kit
25	530 01 91-79	C'case Seal	65	530 01 60-80	Screw
26	530 01 59-41	Retain. Ring-C'shaft	66	530 06 94-00	Starter Pulley
27	530 03 65-78	Muffler Body	67	530 06 93-80	Spark Arrestor Kit
28	530 03 65-77	Muffler Cover	68	530 01 51-62	Piston Pin Retainer
30	530 03 65-79	Muffler Baffle-First	69	530 06 96-21	Piston Kit (Incl. 21, 68 & Pin)
31	530 02 99-30	Muffler Spring	70	530 06 96-60	Muffler Kit
32	530 04 70-90	Shroud & Tank Ass'y.	71	530 01 58-82	Screw
33	530 01 91-81	Gasket-C'case/Shrd	72	530 01 60-90	Screw
34	530 06 96-19	Cylinder Kit	73	530 03 79-72	Bulb Ass'y.
35	530 03 89-04	Carb. Adaptor	74	530 03 77-30	Starter Dog Spring
36	530 01 60-14	Screw	75	530 02 99-30	Starter Dog
37	530 01 92-23	Gasket-Cylinder	76	530 01 58-82	Screw-Flywheel
38	530 06 96-47	Carburetor(WA-218) w/Limiter sap	77	530 06 92-16	Fuel Line-Carb./Prim.
39	530 03 79-66	Air Rot	78	530 06 95-71	Fuel Line-Prim./Tnk.
			79	530 04 72-78	Switch Wire Assty.

MODELL GT21L

Carburetor Assembly #530-069647 – WA-218



KEY NO.	PART NO.	DESCRIPTION
1	530 06 96-68	Carburetor Repair Kit (• Indicates Contents)
2	530 03 84-04	Limiter Cap