

GT21 L

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar

GPL®

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



KEY NO.	PART NO.	DESCRIPTION
13	530 06 96-66	Shield Kit Ass'y. (Incl. 11 & 12)
14	530 01 56-10	Nut-Handle
15	530 03 11-59	Hex Wrench
16	530 40 20-26	Throttle Housing (Left)
17	530 06 92-52	T-Handle Kit
18	530 09 53-06	Drive Shaft Hsg.
19	530 09 45-43	Dust Cup
20	952 71 55-40	Cutting Head Ass'y. (Incl. 21-25)
21	530 09 48-78	Hub Ass'y.
22	530 09 48-30	Spring
23	530 09 48-27	Release Button
24	952 71 55-44	Spool w/Line
25	530 09 48-28	Cover
26	530 02 75-97	Spring

A06

MODEL GT21L

Spark
Arrestor
KitEngine
Gasket
Kit

KEY PART NO. NO.


KEY NO.	PART NO.	DESCRIPTION
1	530 02 93-95	Starter Spring
2	530 01 57-75	Screw
3	530 02 75-23	Retainer
4	530 01 59-34	Screw
5	530 02 75-69	Starter Handle
6	530 01 58-10	Screw
7	530 01 92-33	Gasket-Carb/Cylin.
8	530 03 00-75	Spark Plug
9	530 01 91-94	Gasket-Carb. Adapt.
10	530 01 59-45	Retain. Ring C'case
11	530 01 56-75	Screw-Muffler Guard
12	530 03 70-45	Muffler Guard
13	530 03 91-49	Flywheel Ass'y.
14	530 03 91-63	Ignition Module
15	530 03 61-45	Spacer-Ignition Mod.
16	530 01 59-54	Screw
17	530 01 58-28	Washer
18	530 02 79-53	Drive Coupling
19	530 01 45-32	Crankshaft Ass'y.
20	530 06 96-15	Connecting Rod Ass'y.
21	530 03 64-04	Piston Ring
22	530 01 48-61	Crankcase Ass'y.
23	530 03 21-25	Inner Bearing
24	530 03 21-24	Outer Bearing
25	530 01 91-79	C'case Seal
26	530 01 59-41	Retain. Ring-C'shaft
27	530 03 65-78	Muffler Body
28	530 03 65-77	Muffler Cover
29	530 03 86-02	Muffler Baffle-Exit
30	530 03 65-79	Muffler Baffle-First
31	530 02 99-30	Muffler Spring
32	530 04 70-90	Shroud & Tank Ass'y.
33	530 01 91-81	Gasket-C'case/Shrd
34	530 06 96-19	Cylinder Kit
35	530 06 97-69	Carb. Adaptor
36	530 01 60-14	Screw
37	530 01 92-23	Gasket-Cylinder
38	530 06 96-47	Carburetor (WA-218) w/Limiter Cap
39	530 03 79-66	Air Box

KEY PART NO. NO.

KEY NO.	PART NO.	DESCRIPTION
40	530 03 73-26	Choke Plate
41	530 03 81-02	Choke Shutter
42	530 01 52-54	Wave Washer
43	530 01 58-52	Choke Spacer
44	530 01 58-87	Screw
45	530 03 74-13	Filter Plate
46	530 03 73-31	Air Filter Foam
47	530 03 72-92	Air Filter Cover
48	530 01 59-66	Screw
49	530 03 67-44	Throttle Cable Ass'y.
50	530 01 58-43	Screw
51	530 02 61-19	Check Valve
52	530 02 97-17	Element
53	530 02 96-96	Retainer
54	530 06 92-47	Fuel Line-Tnk./Carb.
55	530 01 43-47	Fuel Cap Ass'y.
56	530 01 43-62	Fuel Pickup Ass'y.
57	530 06 96-25	Engine Gasket Kit
58	530 01 47-29	C'case & C'shaft Assy. (Incl. 10, 19, 22-26)
59	530 04 72-78	Switch Wire Ass'y.
60	530 01 59-53	Screw
61	530 01 60-72	Screw
62	530 01 57-68	Locknut
63	530 04 74-91	Fan Hsg/Shroud Ass'y.
64	530 06 92-32	Rope Kit
65	530 01 60-80	Screw
66	530 06 94-00	Starter Pulley
67	530 06 93-80	Spark Arrestor Kit
68	530 01 51-62	Piston Pin Retainer
69	530 06 96-21	Piston Kit (Incl. 21, 68 & Pin)
70	530 06 96-60	Muffler Kit
71	530 01 58-82	Screw
72	530 01 60-90	Screw
73	530 03 88-74	Bulb Assty.
74	530 04 75-70	Starter Dog Spring
75	530 02 99-39	Starter Dog
76	530 01 58-82	Screw-Flywheel
77	530 06 92-16	Fuel Line-Carb./Prim
78	530 06 95-71	Fuel Line-Prim./Tnk.

MODEL GT21L

Carburetor Assembly #530-069647 – WA-218



KEY NO.	PART NO.	DESCRIPTION
1	530 06 96-68	Carburetor Repair Kit (● Indicates Contents)
2	530 03 84-04	Limiter Cap