

GT26, GT32

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar

GPL®


Model GT26 GT32



Model GT26 GT32

Key no.	Part.No.	Key no.	Part.No.
1	530 01 57-73	51	530 03 91-34
2	530 02 75-29	52	530 01 57-76
3	530 02 75-30	53	530 03 91-36
4	530 01 58-49	54	530 34 79-87
5	530 02 75-28	55	530 02 97-89
6	530 01 52-54	56	530 06 92-91
7	530 02 75-26	57	530 02 93-95
8	530 02 75-27	58	530 02 75-69
9	530 06 92-47	59	530 06 92-32
10	530 01 08-97	60	530 01 42-94
11	530 03 52-59	61	530 09 41-89
12	530 01 91-56	62	530 06 92-54
13	530 01 07-29	63	530 01 57-96
14	530 01 57-75	64	530 00 17-33
15	530 02 75-49	65	530 01 42-98
16	530 02 97-87	66	530 01 57-67
17	530 01 91-54	67	530 02 75-11
18	530 02 75-93	68	530 01 57-70
19	530 02 75-94	69	530 01 57-69
20	530 01 09-60	70	530 01 54-96
21	530 01 09-34	71	530 02 75-23
22	530 01 51-26	72	530 01 57-68
23	530 01 57-72	73	530 06 92-76
24	530 01 57-80	74	952 70 16-12
25	530 02 75-46	77	530 02 75-25 GT 26
26	530 02 75-47	78	530 01 58-23
27	530 01 57-71	79	530 01 58-11 GT 26
28	530 01 40-16	80	504 13 08-08
29	530 02 75-45	81	530 03 51-51
30	530 02 79-58	82	501 78 13-01
31	530 02 79-59	83	501 78 22-01
32	530 01 40-15	84	505 31 67-21
33	530 01 52-41	85	530 03 51-41
34	530 01 51-62	86	501 46 73-01
35	530 02 73-69 GT 26	87	530 03 52-03
36	530 01 91-78	88	501 66 78-01
37	530 06 92-40 GT 26	89	505 52 01-25
38	530 01 57-88	90	505 52 01-27
39	530 03 21-03	91	530 03 51-88
40	530 01 57-87	92	503 11 70-01
41	530 01 91-58	93	530 03 51-78
42	530 03 21-02	94	504 13 08-07
43	530 01 57-89	95	504 13 09-06
44	530 01 57-17	96	505 52 01-30
45	530 02 77-81	97	530 03 51-85
46	530 06 93-10	200	530 06 92-77 GT 32
47	530 02 49-03	201	530 02 58-75 GT 32
48	530 01 22-47 GT 26	202	530 01 22-38 GT 32
49	530 03 00-58	203	530 01 51-28 GT 32
50	530 01 52-39		

Model GT32



Key No.	Part No.
1	530 02 75-95
2	530 01 57-68
3	530 09 49-81
4	530 01 09-58
5	530 01 51-97
6	530 00 16-42
7	530 00 17-11
8	530 09 22-43
9	530 01 57-74
10	530 01 09-59
11	530 06 92-52
12	530 01 53-28
13	530 09 46-12
14	530 09 45-68
15	530 09 45-85
16	530 06 92-56
17	530 01 50-37
18	530 09 45-70
19	530 01 56-53
20	530 09 46-16
21	530 09 46-40
22	530 09 46-39
23	530 09 45-71
24	952 71 55-29
25	530 09 45-57
26	952 71 55-33
27	530 09 44-94
30	530 03 01-02
31	530 09 46-86
32	530 01 56-10
33	530 01 57-84
34	530 01 57-85
36	530 09 20-85

Key No. Part No.



Key No.	Part No.
1	530 02 75-95
2	530 01 57-68
3	530 09 48-91
4	530 01 09-58
6	530 01 57-74
7	530 01 09-59
9	530 06 92-49
10	530 01 50-37
11	530 09 45-70
12	530 01 56-53
13	530 09 36-53
14	530 09 22-43
15	530 09 45-43
16	530 09 45-51
18	530 03 01-02
19	952 71 55-30
20	530 09 46-20
21	952 71 55-33
22	530 09 44-94
23	530 01 57-84
24	530 01 57-85
25	530 01 51-97
27	530 06 92-52

Model GT26 GT32

