

GT26, GT32

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar

GPL®

Model GT32



Key No. Part No.


1	530 02 75-95
2	530 01 57-68
3	530 09 49-81
4	530 01 09-58
5	530 01 51-97
6	530 00 16-42
7	530 00 17-11
8	530 09 22-43
9	530 01 57-74
10	530 01 09-59
11	530 06 92-52
12	530 01 53-28
13	530 09 46-12
14	530 09 45-68
15	530 09 45-85
16	530 06 92-56
17	530 01 50-37
18	530 09 45-70
19	530 01 56-53
20	530 09 46-16
21	530 09 46-40
22	530 09 46-39
23	530 09 45-71
24	952 71 55-29
25	530 09 45-57
26	952 71 55-33
27	530 09 44-94
30	530 03 01-02
31	530 09 46-86
32	530 01 56-10
33	530 01 57-84
34	530 01 57-85
36	530 09 20-85

Key No 1



Key No.	Part No.
1	530 02 75-95
2	530 01 57-68
3	530 09 48-91
4	530 01 09-58
6	530 01 57-74
7	530 01 09-59
9	530 06 93-11
10	530 01 50-37
11	530 09 45-70
12	530 01 56-53
13	530 09 36-53
14	530 09 22-43
15	530 09 45-43
16	530 09 45-51
18	530 03 01-02
19	952 71 55-30
20	530 09 46-20
21	952 71 55-33
22	530 09 44-94
23	530 01 57-84
24	530 01 57-85
25	530 01 51-97
27	530 06 92-52

Model GT26 GT32



Model GT26 GT32

Key no. Part.No.

1	530 01 57-73
2	530 02 75-29
3	530 02 75-30
4	530 01 58-49
5	530 02 75-28
6	530 01 52-54
7	530 02 75-26
8	530 02 75-27
9	530 06 92-47
10	530 01 08-97
11	530 03 52-59
12	530 01 91-56
13	530 01 07-29
14	530 01 57-75
15	530 02 75-49
16	530 02 97-87
17	530 01 91-54
18	530 02 75-93
19	530 02 75-94
20	530 01 09-60
21	530 01 09-34
22	530 01 51-26
23	530 01 57-72
24	530 01 57-80
25	530 02 75-46
26	530 02 75-47
27	530 01 57-71
28	530 01 40-16
29	530 02 75-45
30	530 02 79-58
31	530 02 79-59
32	530 01 40-15
33	530 01 52-41
34	530 01 51-62
35	530 02 73-69 GT 26
37	530 06 92-40
38	530 01 57-88
39	530 03 21-03
40	530 01 57-87
41	530 01 91-58
42	530 03 21-02
43	530 01 57-89
44	530 01 57-17
45	530 02 77-81
46	530 06 93-10
47	530 02 49-03
48	530 01 22-47 GT 26
49	530 03 00-58
50	530 01 52-39

Key no. Part.No.

51	530 03 91-34
52	530 01 57-76
53	530 03 91-36
54	530 34 79-87
55	530 02 97-89
56	530 06 92-91
57	530 02 93-95
58	530 02 75-69
59	530 06 92-32
60	530 01 42-94
61	530 09 41-89
62	530 06 92-54
63	530 01 57-96
64	530 00 17-33
65	530 01 42-98
66	530 01 57-67
67	530 02 75-11
68	530 01 57-70
69	530 01 57-69
70	530 01 54-96
71	530 02 75-23
72	530 01 57-68
73	530 06 92-76
74	952 70 16-12
77	530 02 75-25 GT 26
78	530 01 58-23
79	530 01 58-11 GT 26
80	504 13 08-08
81	530 03 51-51
82	501 78 13-01
83	501 78 22-01
84	505 31 67-21
85	530 03 51-41
86	501 46 73-01
87	530 03 52-03
88	501 66 78-01
89	505 52 01-25
90	505 52 01-27
91	530 03 51-88
92	503 11 70-01
93	530 03 51-78
94	504 13 08-07
95	504 13 09-06
96	505 52 01-30
97	530 03 51-85
200	530 06 92-77 GT 32
201	530 02 58-75 GT 32
202	530 01 22-38 GT 32
203	530 01 51-28 GT 32

Model GT26 GT32

