

## **ILLUSTRATED PARTS LIST**

**MODEL NUMBER SB240**

**PRODUCT NUMBER 961 91 00-05**


**MFG. ID. NUMBER 96191000512**



## REPAIR PARTS

## AUGER HOUSING / IMPELLER ASSEMBLY

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05



**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

**REPAIR PARTS****AUGER HOUSING / IMPELLER ASSEMBLY****SNOW THROWER - MODEL NO. SB240 (96191000512), PRODUCT NO. 961 91 00-05**

| KEY NO. | PART NO.     | DESCRIPTION                                                                                          |
|---------|--------------|------------------------------------------------------------------------------------------------------|
| 1       | 532 18 41-05 | IMPELLER                                                                                             |
| 2       | 532 19 67-10 | GEARBOX ASSEMBLY                                                                                     |
| 3       | 532 18 89-09 | BEARING                                                                                              |
| 4       | 532 19 10-79 | IMPELLER PULLEY                                                                                      |
| 5       | 532 17 53-22 | DISCHARGE BASE                                                                                       |
| 6       | 532 18 40-95 | CORNER BRACKET                                                                                       |
| 7       | 532 19 21-99 | CLEAN OUT TOOL                                                                                       |
| 8       | 532 40 54-00 | TOOL CLIP                                                                                            |
| 9       | 873 80 04-00 | NUT 1/4-20                                                                                           |
| 10      | 874 78 04-26 | SCREW 1/4-20 X .625                                                                                  |
| 11      | 532 15 53-77 | NUT 5/16-18                                                                                          |
| 12      | 532 16 31-83 | SCREW 5/16-18 X .625                                                                                 |
| 13      | 819 11 15-07 | WASHER                                                                                               |
| 14      | 810 04 05-00 | LOCKWASHER 5/16                                                                                      |
| 15      | 874 94 05-16 | SCREW 5/16-18 X 1.00                                                                                 |
| 16      | 532 18 03-55 | CARRIAGE BOLT                                                                                        |
| 17      | 532 19 41-89 | SCREW 13-16 X .625                                                                                   |
| 18      | 532 40 77-60 | PLUG                                                                                                 |
| 19      | 532 40 77-61 | GEARBOX COVER RH  |
| 20      | 532 40 77-66 | GASKET                                                                                               |
| 21      | 532 40 77-70 | SEAL                                                                                                 |
| 22      | 532 40 77-62 | BEARING                                                                                              |
| 23      | 532 17 46-97 | THRUST WASHER 1.00                                                                                   |
| 24      | 532 40 77-63 | WORM GEAR                                                                                            |
| 25      | 532 40 77-64 | AUGER SHAFT                                                                                          |
| 26      | 532 18 92-82 | SQUARE KEY                                                                                           |
| 27      | 532 40 77-58 | BEARING                                                                                              |
| 28      | 532 17 46-83 | THRUST WASHER                                                                                        |
| 29      | 532 40 77-57 | IMPELLER SHAFT                                                                                       |
| 30      | 532 18 42-05 | ROLL PIN                                                                                             |
| 31      | 532 17 46-81 | THRUST WASHER                                                                                        |
| 32      | 532 17 46-84 | THRUST BEARING                                                                                       |
| 33      | 532 40 77-69 | BEARING                                                                                              |
| 34      | 532 40 77-68 | O-RING                                                                                               |
| 35      | 532 40 77-67 | SCREW 5/16-18 X .750                                                                                 |
| 36      | 532 40 77-65 | GEARBOX COVER LH                                                                                     |


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS


## AUGER HOUSING / IMPELLER ASSEMBLY

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05



01.07.001-A

| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 1       | 532 41 52-95 | AUGER HOUSING                |
| 2       | 532 41 62-15 | SCRAPER BAR                  |
| 3       | 872 27 05-05 | CARRIAGE BOLT 5/16-18 X .625 |
| 4       | 532 15 53-77 | NUT 5/16-18                  |



01.07.008-A


| KEY NO. | PART NO.     | DESCRIPTION |
|---------|--------------|-------------|
| 1       | 532 40 78-66 | AUGER 24 LH |
| 2       | 532 40 78-50 | AUGER 24 RH |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.


REPAIR PARTS

AUGER HOUSING / IMPELLER ASSEMBLY

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05



| KEY NO. | PART NO.     | DESCRIPTION          |
|---------|--------------|----------------------|
| 1       | 532 17 46-58 | AUGER BEARING        |
| 2       | 532 41 19-39 | BEARING PLUG         |
| 3       | 532 17 95-82 | SCREW 5/16-18 X 1.00 |



| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 1       | 532 18 40-93 | SKID PLATE LH               |
| 2       | 532 18 40-94 | SKID PLATE RH               |
| 3       | 872 27 05-06 | CARRIAGE BOLT 5/16-18 X .75 |
| 4       | 532 75 11-53 | NUT 5/16-18                 |


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

REPAIR PARTS

CONTROL PANEL / DISCHARGE CHUTE

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05




| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 1       | 532 40 77-32 | CHUTE WELDMENT               |
| 2       | 532 18 45-11 | DEFLECTOR WELDMENT           |
| 3       | 532 42 03-25 | DEFLECTOR SEAL               |
| 4       | 532 18 41-14 | STRAP                        |
| 5       | 532 19 19-38 | KNOB BLACK                   |
| 6       | 532 12 84-15 | POP RIVET                    |
| 7       | 532 18 56-00 | SHOULDER BOLT 1/4-20 X .704  |
| 8       | 872 27 05-05 | CARRIAGE BOLT 5/16-18 X .625 |
| 9       | 532 19 17-30 | NUT 1/4-20                   |
| 10      | 532 15 54-15 | WASHER                       |
| 11      | 532 17 92-46 | PLASTIC WASHER               |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## CONTROL PANEL / DISCHARGE CHUTE SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05



| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 1       | 532 42 03-37 | LEVER/CABLE ROTATOR ASSEMBLY |
| 2       | 817 50 10-10 | SCREW 10-24 X .625           |
| *3      | 532 42 06-78 | ROTATOR HEAD                 |
| *4      | 532 42 06-77 | ROTATOR PIVOT BRACKET        |
| *5      | 532 42 06-75 | PULLEY PIVOT                 |
| *6      | 532 42 06-74 | CABLE ASSEMBLY               |

### NOTES:

1. ITEMS INDICATED WITH AN \* ARE LISTED AS REFERENCE FOR SERVICE PARTS ONLY.


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## HANDLES

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05



01.08.002-D

| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 1       | 532 41 55-39 | CONTROL PANEL               |
| 2       | 532 41 55-41 | CONTROL LEVER LH            |
| 3       | 532 41 55-42 | CONTROL LEVER RH            |
| 4       | 532 41 55-46 | TRACTION ROD ARM            |
| 5       | 532 19 95-76 | IMPELLER ROD ARM            |
| 6       | 532 41 26-77 | INTERLOCK ROD               |
| 7       | 532 41 26-80 | SPACER                      |
| 8       | 532 16 96-75 | RETAINER                    |
| 9       | 817 06 04-08 | SCREW 1/4-20 X .50          |
| 10      | 532 41 42-80 | KNOB BLACK                  |
| 11      | 532 41 42-81 | KNOB RED                    |
| 12      | 532 17 88-99 | HANDLE KNOB                 |
| 13      | 819 13 13-16 | WASHER 3/8                  |
| 14      | 872 12 06-18 | CARRIAGE BOLT 3/8-16 X 2.25 |


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

REPAIR PARTS


HANDLES

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05



| KEY NO. | PART NO.     | DESCRIPTION          |
|---------|--------------|----------------------|
| 1       | 532 42 11-20 | LOOP HANDLE LH       |
| 2       | 532 42 11-21 | LOOP HANDLE RH       |
| 3       | 874 78 05-24 | SCREW 5/16-18 X 1.50 |
| 4       | 874 78 05-28 | SCREW 5/16-18 X 1.75 |
| 5       | 532 75 11-53 | NUT 5/16-18          |

01.08.004-A



| KEY NO. | PART NO.     | DESCRIPTION         |
|---------|--------------|---------------------|
| 1       | 532 41 62-88 | INTERLOCK SPRING    |
| 2       | 532 41 45-72 | INTERLOCK CAM       |
| 3       | 532 17 88-31 | TORSION SPRING      |
| 4       | 532 16 96-75 | RETAINER            |
| 5       | 817 06 04-10 | SCREW 1/4-20 X .625 |
| 6       | 532 42 18-14 | INTERLOCK STOP      |

01.08.007-B


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

# REPAIR PARTS

# HANDLES

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05





**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
 Failure to do so could be hazardous, damage your snow thrower and void your warranty.


**REPAIR PARTS**

**HANDLES**

**SNOW THROWER - MODEL NO. SB240 (96191000512), PRODUCT NO. 961 91 00-05**



**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.



**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm


**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

**REPAIR PARTS****DRIVE****SNOW THROWER - MODEL NO. SB240 (96191000512), PRODUCT NO. 961 91 00-05**

| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 1       | 532 19 84-74 | SPEED SELECTOR HEAD ASSEMBLY |
| 2       | 817 50 10-10 | SCREW 10-24 X .625           |
| 3       | 532 19 77-63 | DRIVE PLATE WELDMENT         |
| 4       | 532 19 77-64 | HEX SHAFT                    |
| 5       | 532 17 53-44 | TRUNNION BEARING ASSEMBLY    |
| 6       | 812 00 00-12 | RETAINER                     |
| 7       | 872 27 05-05 | CARRIAGE BOLT 5/16-18 X .625 |
| 8       | 532 18 89-09 | FLANGE BEARING               |
| 9       | 532 18 25-04 | SPACER                       |
| 10      | 532 18 40-77 | LEVER SHIFTER PLATE          |
| 11      | 532 18 40-76 | SHIFTER SUPPORT BRACKET      |
| 12      | 532 17 86-95 | PIN                          |
| 13      | 532 08 51-79 | RETAINER                     |
| 14      | 817 49 04-08 | SCREW 1/4-20 X .500          |
| 15      | 817 49 05-08 | BOLT 5/16-18 X .500          |
| 16      | 532 18 40-75 | DRIVE MOUNT PLATE            |
| 17      | 532 15 53-77 | NUT 5/16-18                  |
| 18      | 532 19 10-80 | TRACTION PULLEY              |
| 19      | 819 11 15-07 | WASHER                       |
| 20      | 810 04 05-00 | LOCKWASHER 5/16              |
| 21      | 874 95 05-12 | SCREW 5/16-18 X .750         |
| 22      | 532 42 21-11 | IDLER BRAKE ARM              |
| 23      | 532 18 05-23 | IDLER PULLEY                 |
| 24      | 532 18 40-74 | IDLER PIVOT BRACKET          |
| 25      | 532 17 53-30 | PIN                          |
| 26      | 874 78 05-24 | SCREW 5/16-18 X 1.50         |
| 27      | 532 16 67-85 | NUT 5/16-18                  |
| 28      | 532 18 10-44 | TRACTION SPRING              |
| 29      | 532 18 48-04 | IDLER TRACTION ARM           |
| 30      | 532 18 05-22 | IDLER PULLEY                 |
| 31      | 874 78 05-20 | SCREW 5/16-18 X 1.25         |
| 32      | 532 05 92 89 | WASHER                       |
| 33      | 873 93 05-00 | NUT 5/16-18                  |
| 34      | 532 85 10-84 | SCREW 3/8-24 X 1.38          |
| 35      | 532 85 02-63 | LOCKWASHER 3/8               |
| 36      | 532 40 00-26 | WASHER                       |
| 37      | 532 18 04-78 | ENGINE TRACTION PULLEY       |
| 38      | 532 40 94-75 | SPACER                       |
| 39      | 532 17 90-95 | RETURN SPRING                |
| 40      | 532 15 54-52 | BELT GUIDE                   |
| 41      | 874 61 05-16 | SCREW 5/16-18 X 1.00         |
| 42      | 532 17 53-31 | BUSHING                      |
| 43      | 811 05 05-00 | LOCKWASHER 5/16              |
| 44      | 532 17 88-28 | BRAKE SPRING                 |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.



01.02.001-F\_Sheet\_1

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
 Failure to do so could be hazardous, damage your snow thrower and void your warranty.

**REPAIR PARTS****DRIVE****SNOW THROWER - MODEL NO. SB240 (96191000512), PRODUCT NO. 961 91 00-05**

| KEY NO. | PART NO.     | DESCRIPTION               |
|---------|--------------|---------------------------|
| 1       | 817 49 05-08 | BOLT 5/16-18 X .500       |
| 2       | 532 75 11-53 | NUT 5/16-18               |
| 3       | 532 18 00-17 | FLANGE BEARING            |
| 4       | 873 93 05-00 | NUT 5/16-18               |
| 5       | 532 19 95-09 | RUBBER WHEEL PLATE        |
| 6       | 532 17 98-31 | RUBBER WHEEL RING         |
| 7       | 532 17 86-13 | RUBBER WHEEL HUB          |
| 8       | 874 76 05-14 | BOLT 5/16-18 X .875       |
| 9       | 532 17 53-44 | TRUNNION BEARING ASSEMBLY |
| 10      | 812 00 00-12 | RETAINER                  |
| 11      | 532 18 00-66 | HEX SHAFT                 |
| 12      | 532 18 00-65 | PINION GEAR               |
| 13      | 532 19 29-07 | AUXILIARY PLATE           |
| 14      | 532 17 92-70 | SPACER PLATE              |
| 15      | 532 18 00-82 | INTERMEDIATE GEAR         |
| 16      | 532 18 01-34 | AUXILIARY SHAFT           |
| 17      | 532 40 54-85 | CONTROL ARM               |
| 18      | 532 05 70-79 | WASHER                    |
| 19      | 532 40 61-09 | CONTROL SHAFT ASSEMBLY    |
| 20      | 532 19 85-80 | CLEVIS PIN                |
| 21      | 532 18 40-80 | SHIFTER LEVER             |
| 22      | 532 18 78-57 | PIVOT BRACKET             |
| 23      | 532 17 88-07 | PIVOT PIN                 |
| 24      | 532 18 01-35 | SPRING                    |
| 25      | 532 18 71-01 | SHIFTER LINK              |
| 26      | 532 08 51-79 | RETAINER                  |
| 27      | 532 70 02-79 | CLIP                      |
| 28      | 532 15 00-78 | BOLT 5/16-18 x .750       |



**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## CHASSIS / PULLEYS

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05




**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
 Failure to do so could be hazardous, damage your snow thrower and void your warranty.

REPAIR PARTS


CHASSIS / PULLEYS

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05



| KEY NO. | PART NO.     | DESCRIPTION                        |
|---------|--------------|------------------------------------|
| -       | -----        | TEC ENGINE<br>MODEL OH195SA-72536G |
| 1       | 532 41 55-11 | FRAME                              |
| 2       | 532 41 08-77 | BOTTOM PAN                         |
| 3       | 532 15 04-06 | BOLT 3/8-16                        |
| 4       | 532 18 44-71 | SCREW 10-24 X .625                 |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.



| KEY NO. | PART NO.     | DESCRIPTION       |
|---------|--------------|-------------------|
| 1       | 532 41 52-93 | WHEEL ASSEMBLY LH |
| 2       | 532 41 53-36 | WHEEL ASSEMBLY RH |






**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.

**REPAIR PARTS**

**BAG OF PARTS**

**SNOW THROWER - MODEL NO. SB240 (96191000512), PRODUCT NO. 961 91 00-05**



| KEY NO. | PART NO.     | DESCRIPTION               |
|---------|--------------|---------------------------|
| 1       | 532 16 96-75 | RETAINER PIN              |
| 2       | 532 18 06-84 | WRENCH                    |
| 3       | 873 80 06-00 | LOCKNUT 3/8-16            |
| 4       | 819 13 13-16 | WASHER 3/8                |
| 5       | 532 19 86-36 | SHEAR BOLT 1/4-20 X 1-3/4 |
| 6       | 532 19 86-38 | SPACER                    |
| 7       | 873 80 04-00 | LOCKNUT 1/4-20            |




**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## DECALS

SNOW THROWER - MODEL NO. **SB240** (96191000512), PRODUCT NO. 961 91 00-05



| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 1       | 532 19 96-83 | DECAL, DANGER                   |
| 2       | 532 41 48-48 | DECAL, PARTNER                  |
| 3       | 532 19 96-82 | DECAL, DANGER, DEFLECTOR        |
| 4       | 532 18 40-45 | DECAL, DANGER                   |
| 5       | 532 41 48-83 | DECAL, PARTNER, SB240           |
| 6       | 532 18 40-30 | DECAL, INSTRUCTION              |
| 7       | 532 41 53-93 | DECAL, TRACTION LEVER           |
| 8       | 532 41 53-92 | DECAL, AUGER LEVER              |
| 9       | 532 41 54-77 | DECAL, SPEED CONTROL            |
| --      | 532 40 58-98 | OPERATOR'S MANUAL, EUROPEAN     |
| --      | 532 40 58-99 | OPERATOR'S MANUAL, SCANDANIVIAN |
| --      | 532 40 58-97 | OPERATOR'S MANUAL, EAST BLOC    |
| --      | 532 40 92-49 | OPERATOR'S MANUAL, BALTIC       |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.