

# ST2111 E


Spare parts  
Ersatzteile  
Pièces détachées  
Reserve onderdelen  
Repuestos  
Reservdelar

GPL®

## REPAIR PARTS

## AUGER HOUSING / IMPELLER ASSEMBLY

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## AUGER HOUSING / IMPELLER ASSEMBLY

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22

| KEY NO. | PART NO.     | DESCRIPTION           |
|---------|--------------|-----------------------|
| 1       | 532 18 41-05 | IMPELLER              |
| 2       | 532 19 67-10 | GEARBOX ASSEMBLY      |
| 3       | 532 18 89-09 | BEARING               |
| 4       | 532 42 70-71 | IMPELLER PULLEY       |
| 5       | 532 17 53-22 | DISCHARGE BASE        |
| 6       | 532 18 40-95 | CORNER BRACKET        |
| 7       | 532 19 21-99 | CLEAN OUT TOOL        |
| 8       | 532 40 54-00 | TOOL CLIP             |
| 9       | 873 80 04-00 | NUT 1/4-20            |
| 10      | 874 78 04-26 | SCREW 1/4-20 X .625   |
| 11      | 532 42 79-42 | NUT 5/16-18           |
| 12      | 532 16 31-83 | SCREW 5/16-18 X .625  |
| 13      | 819 11 15-07 | WASHER                |
| 14      | 810 04 05-00 | LOCKWASHER 5/16       |
| 15      | 874 94 05-16 | SCREW 5/16-18 X 1 .00 |
| 16      | 532 18 03-55 | CARRIAGE BOLT         |
| 17      | 532 19 41-89 | SCREW 13-16 X .625    |
| 18      | 532 40 77-60 | PLUG                  |
| 19      | 532 40 77-61 | GEARBOX COVER RH      |
| 20      | 532 40 77-66 | GASKET                |
| 21      | 532 40 77-70 | SEAL                  |
| 22      | 532 40 77-62 | BEARING               |
| 23      | 532 17 46-97 | THRUST WASHER 1.00    |
| 24      | 532 40 77-63 | WORM GEAR             |
| 25      | 532 40 77-64 | AUGER SHAFT           |
| 26      | 532 18 92-82 | SQUARE KEY            |
| 27      | 532 40 77-58 | BEARING               |
| 28      | 532 17 46-83 | THRUST WASHER         |
| 29      | 532 40 77-57 | IMPELLER SHAFT        |
| 30      | 532 18 42-05 | ROLL PIN              |
| 31      | 532 17 46-81 | THRUST WASHER         |
| 32      | 532 17 46-84 | THRUST BEARING        |
| 33      | 532 40 77-69 | BEARING               |
| 34      | 532 40 77-68 | O-RING                |
| 35      | 532 40 77-67 | SCREW 5/16-18 X .750  |
| 36      | 532 40 77-65 | GEARBOX COVER LH      |
| 37      | 532 19 20-90 | SHEAR BOLT            |


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS


## AUGER HOUSING / IMPELLER ASSEMBLY

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



| KEY NO. | PART NO.     | DESCRIPTION               |
|---------|--------------|---------------------------|
| 1       | 532 40 82-70 | AUGER HOUSING             |
| 2       | 532 40 76-45 | SCRAPPER BAR              |
| 3       | 872 27 05-05 | CARRIAGEBOLT 5/16-18X.625 |
| 4       | 532 15 53-77 | NUT 5/16-18               |

01.07.003-A



| KEY NO. | PART NO.     | DESCRIPTION          |
|---------|--------------|----------------------|
| 1       | 532 42 40-20 | PLASTIC RETAINER     |
| 2       | 532 41 18-33 | AUGER BALL BEARING   |
| 3       | 532 17 95-82 | SCREW 5/16-18 X 1.00 |


01.07.007-B

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm


**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.

**REPAIR PARTS**

**AUGER HOUSING / IMPELLER ASSEMBLY**  
**SNOW THROWER - MODEL NO. ST2111E (96191002204), PRODUCT NO. 961 91 00-22**



| KEY NO. | PART NO.     | DESCRIPTION          |
|---------|--------------|----------------------|
| 1       | 532 42 11-24 | AUGER ASSEMBLY 30 LH |
| 2       | 532 42 11-25 | AUGER ASSEMBLY 30 RH |




| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 1       | 532 18 40-93 | SKID PLATE LH               |
| 2       | 532 18 40-94 | SKID PLATE RH               |
| 3       | 872 27 05-06 | CARRIAGE BOLT 5/16-18 X .75 |
| 4       | 532 75 11-53 | NUT 5/16-18                 |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.


REPAIR PARTS

AUGER HOUSING / IMPELLER ASSEMBLY

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 1       | 532 18 47-47 | DRIFT CUTTER BAR             |
| 2       | 872 27 05-06 | CARRIAGE BOLT 5/16-18 X .750 |
| 3       | 532 17 92-46 | PLASTIC WASHER               |
| 4       | 810 04 05-00 | LOCKWASHER 5/16              |
| 5       | 532 12 86-38 | NUT 5/16-18                  |




| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 1       | 532 18 25-16 | WEIGHT BAR                   |
| 2       | 872 11 05-10 | CARRIAGE BOLT 5/16-18 X 1.25 |
| 3       | 532 75 11-53 | NUT 5/16-18                  |
| 4       | 819 11 22-06 | WASHER                       |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.

REPAIR PARTS

CONTROL PANEL / DISCHARGE CHUTE

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



**NOTE:**

1. ALL ITEMS INDICATED WITH AN \* ARE PROVIDED IN THE BAG OF ITEMS SHIPPED LOOSE WITH PRODUCT.

2. ITEMS 13 AND 14 ARE SERVICE PART NUMBERS TO ALLOW PURCHASE OF INDIVIDUAL ITEMS IF NECESSARY.


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## CONTROL PANEL / DISCHARGE CHUTE

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 1       | 532 42 03-37 | LEVER/CABLE ROTATOR ASSEMBLY |
| 2       | 817 50 10-10 | SCREW 10-24 X .625           |
| *3      | 532 42 06-78 | ROTATOR HEAD                 |
| *4      | 532 42 06-77 | ROTATOR PIVOT BRACKET        |
| *5      | 532 42 06-75 | PULLEY PIVOT                 |
| *6      | 532 42 06-74 | CABLE ASSEMBLY               |

### NOTES:

1. ITEMS INDICATED WITH AN \* ARE LISTED AS REFERENCE FOR SERVICE PARTS ONLY.


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## HANDLES

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



01.08.002-F

| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 1       | 532 41 55-39 | CONTROL PANEL               |
| 2       | 532 42 88-59 | CONTROL LEVER LH            |
| 3       | 532 42 88-60 | CONTROL LEVER RH            |
| 4       | 532 42 90-97 | TRACTION ROD ARM            |
| 5       | 532 42 90-98 | IMPELLER ROD ARM            |
| 6       | 532 41 26-77 | INTERLOCK ROD               |
| 7       | 532 42 16-13 | SPACER                      |
| 8       | 532 16 96-75 | RETAINER                    |
| 9       | 817 06 04-10 | SCREW 1/4-20 X .62          |
| 10      | 532 41 42-80 | KNOB BLACK                  |
| 11      | 532 41 42-81 | KNOB RED                    |
| 12      | 532 17 88-99 | HANDLE KNOB                 |
| 13      | 819 13 13-16 | WASHER 3/8                  |
| 14      | 872 12 06-18 | CARRIAGE BOLT 3/8-16 X 2.25 |


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS


## HANDLES

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



| KEY NO. | PART NO.     | DESCRIPTION          |
|---------|--------------|----------------------|
| 1       | 532 42 10-69 | PLOW HANDLE LH       |
| 2       | 532 42 10-70 | PLOW HANDLE RH       |
| 3       | 532 42 91-48 | PANEL BRACKET LH     |
| 4       | 532 42 91-49 | PANEL BRACKET RH     |
| 5       | 532 41 45-15 | HEATED HANDLE GRIP   |
| 6       | 874 78 05-12 | CREW 5/16-18 X .750  |
| 7       | 874 78 05-24 | SCREW 5/16-18 X 1.50 |
| 8       | 532 75 11-53 | NUT 5/16-18          |
| 9       | 532 15 54-15 | WASHER               |
| 10      | 532 17 87-75 | POP RIVET 1/8        |

01.08.005-A



| KEY NO. | PART NO.     | DESCRIPTION         |
|---------|--------------|---------------------|
| 1       | 532 41 62-88 | INTERLOCK SPRING    |
| 2       | 532 41 45-72 | INTERLOCK CAM       |
| 3       | 532 17 88-31 | TORSION SPRING      |
| 4       | 532 16 96-75 | RETAINER            |
| 5       | 817 06 04-10 | SCREW 1/4-20 X .625 |
| 6       | 532 42 18-14 | INTERLOCK STOP      |


01.08.007-B

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
 Failure to do so could be hazardous, damage your snow thrower and void your warranty.

# REPAIR PARTS

# HANDLES

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22




| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 1       | 532 18 04-80 | IMPELLER ROD ASSEMBLY        |
| 2       | 532 40 57-40 | TRACTION ROD ASSEMBLY        |
| 3       | 532 18 04-45 | SHIFTER ROD TOP              |
| 4       | 532 18 77-16 | SHIFTER ROD BOTTOM           |
| 5       | 532 18 04-47 | SPRING SLEEVE                |
| 6       | 532 17 86-69 | IMPELLER SPRING              |
| 7       | 532 18 09-26 | TRACTION SPRING              |
| 8       | 872 27 05-06 | CARRIAGE BOLT 5/16-18 X .750 |
| 9       | 532 15 53-77 | NUT 5/16-18                  |
| 10      | 532 16 96-75 | RETAINER                     |
| 11      | 532 40 33-00 | CLUTCH ROD                   |
| 12      | 532 41 75-39 | REAR PLATE                   |
| 13      | 532 41 54-33 | SHIFTER PLATE BRACKET        |
| 14      | 532 41 68-64 | CLUTCH PLATE BRACKET         |
| 15      | 532 41 54-35 | CLUTCH PLATE                 |
| 16      | 532 41 54-50 | SHIFTER PLATE                |
| 17      | 532 42 88-67 | BOLT 5/16-18 X .750          |
| 18      | 532 40 28-81 | SHOULDER BOLT 1/4-20 X .500  |
| 19      | 532 19 17-30 | NUT 1/4-20                   |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
 Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS


## HANDLES

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



01.05.001-C

| KEY NO. | PART NO.     | DESCRIPTION         |
|---------|--------------|---------------------|
| 1       | 532 42 10-59 | LOWER TUBE          |
| 2       | 532 41 54-89 | PIVOT SUPPORT       |
| 3       | 532 42 88-67 | BOLT 5/16-18 X .750 |
| 4       | 817 00 06-16 | SCREW 3/8-16 X 1.00 |



01.10.009-B


| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 1       | 532 40 58-79 | CONSOLE PANEL               |
| 2       | 532 17 86-68 | HEADLIGHT BEZEL             |
| 3       | 532 17 86-66 | HALOGEN HEADLIGHT           |
| 4       | 532 18 44-71 | SHOULDER SCREW 10-24 X .625 |
| 5       | 532 17 52-62 | SCREW 10-24 X 1.25          |
| 6       | 532 40 57-81 | GRIP SWITCH                 |
| 7       | 532 40 56-99 | WIRE HARNESS                |
| 8       | 532 40 16-20 | BULB                        |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
 Failure to do so could be hazardous, damage your snow thrower and void your warranty.

# REPAIR PARTS

# DRIVE


SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



01.02.001-G\_Sheet\_1

| KEY NO. | PART NO.     | DESCRIPTION               | KEY NO. | PART NO.     | DESCRIPTION            |
|---------|--------------|---------------------------|---------|--------------|------------------------|
| 1       | 817 49 05-08 | BOLT 5/16-18 X .500       | 14      | 532 17 92-70 | SPACER PLATE           |
| 2       | 532 75 11-53 | NUT 5/16-18               | 15      | 532 18 00-82 | INTERMEDIATE GEAR      |
| 3       | 532 18 00-17 | FLANGE BEARING            | 16      | 532 18 01-34 | AUXILIARY SHAFT        |
| 4       | 873 93 05-00 | NUT 5/16-18               | 17      | 532 40 54-85 | CONTROL ARM            |
| 5       | 532 19 95-09 | RUBBER WHEEL PLATE        | 18      | 532 05 70-79 | WASHER                 |
| 6       | 532 17 98-31 | RUBBER WHEEL RING         | 19      | 532 40 61-09 | CONTROL SHAFT ASSEMBLY |
| 7       | 532 17 86-13 | RUBBER WHEEL HUB          | 20      | 532 19 85-80 | CLEVIS PIN             |
| 8       | 874 76 05-14 | BOLT 5/16-18 X .875       | 21      | 532 18 40-80 | SHIFTER LEVER          |
| 9       | 532 17 53-44 | TRUNNION BEARING ASSEMBLY | 22      | 532 18 78-57 | PIVOT BRACKET          |
| 10      | 812 00 00-12 | RETAINER                  | 23      | 532 17 88-07 | PIVOT PIN              |
| 11      | 532 18 00-66 | HEX SHAFT                 | 24      | 532 18 01-35 | SPRING                 |
| 12      | 532 18 00-65 | PINION GEAR               | 25      | 532 18 71-01 | SHIFTER LINK           |
| 13      | 532 19 29-07 | AUXILIARY PLATE           | 26      | 532 08 51-79 | RETAINER               |
|         |              |                           | 27      | 532 70 02-79 | CLIP                   |
|         |              |                           | 28      | 532 42 88-67 | BOLT 5/16-18 x .750    |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
 Failure to do so could be hazardous, damage your snow thrower and void your warranty.



01.02.001-G\_Sheet\_2

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
 Failure to do so could be hazardous, damage your snow thrower and void your warranty.

**REPAIR PARTS****DRIVE****SNOW THROWER - MODEL NO. ST2111E (96191002204), PRODUCT NO. 961 91 00-22**

| KEY NO. | PART NO.     | DESCRIPTION                  |
|---------|--------------|------------------------------|
| 1       | 532 19 84-74 | SPEED SELECTOR HEAD ASSEMBLY |
| 2       | 817 50 10-10 | SCREW 10-24 X .625           |
| 3       | 532 19 77-63 | DRIVE PLATE WELDMENT         |
| 4       | 532 19 77-64 | HEX SHAFT                    |
| 5       | 532 17 53-44 | TRUNNION BEARING ASSEMBLY    |
| 6       | 812 00 00-12 | RETAINER                     |
| 7       | 872 27 05-05 | CARRIAGE BOLT 5/16-18 X .625 |
| 8       | 532 18 89-09 | FLANGE BEARING               |
| 9       | 532 18 25-04 | SPACER                       |
| 10      | 532 18 40-77 | LEVER SHIFTER PLATE          |
| 11      | 532 18 40-76 | SHIFTER SUPPORT BRACKET      |
| 12      | 532 17 86-95 | PIN                          |
| 13      | 532 08 51-79 | RETAINER                     |
| 14      | 817 49 04-08 | SCREW 1/4-20 X .500          |
| 15      | 817 49 05-08 | BOLT 5/16-18 X .500          |
| 16      | 532 18 40-75 | DRIVE MOUNT PLATE            |
| 17      | 532 15 53-77 | NUT 5/16-18                  |
| 18      | 532 19 10-80 | TRACTION PULLEY              |
| 19      | 819 11 15-07 | WASHER                       |
| 20      | 810 04 05-00 | LOCKWASHER 5/16              |
| 21      | 874 95 05-12 | SCREW 5/16-18 X .750         |
| 22      | 532 42 21-11 | IDLER BRAKE ARM              |
| 23      | 532 18 05-23 | IDLER PULLEY                 |
| 24      | 532 18 40-74 | IDLER PIVOT BRACKET          |
| 25      | 532 17 53-30 | PIN                          |
| 26      | 874 78 05-24 | SCREW 5/16-18 X 1.50         |
| 27      | 532 42 65-89 | NUT 5/16-18                  |
| 28      | 532 18 10-44 | TRACTION SPRING              |
| 29      | 532 17 93-54 | IDLER TRACTION ARM           |
| 30      | 532 18 05-22 | IDLER PULLEY                 |
| 31      | 874 78 05-20 | SCREW 5/16-18 X 1.25         |
| 32      | 532 05 92-89 | WASHER                       |
| 33      | 873 93 05-00 | NUT 5/16-18                  |
| 34      | 532 85 10-84 | SCREW 3/8-24 X 1.38          |
| 35      | 532 85 02-63 | LOCKWASHER 3/8               |
| 36      | 532 40 00-26 | WASHER                       |
| 37      | 532 18 04-78 | ENGINE TRACTION PULLEY       |
| 38      | 532 40 94-75 | SPACER                       |
| 39      | 532 17 90-95 | RETURN SPRING                |
| 40      | 532 15 54-52 | BELT GUIDE                   |
| 41      | 874 61 05-16 | SCREW 5/16-18 X 1.00         |
| 42      | 532 17 53-31 | BUSHING                      |
| 43      | 811 05 05-00 | LOCKWASHER 5/16              |
| 44      | 532 17 88-28 | BRAKE SPRING                 |
| 45      | 532 42 88-67 | BOLT HEX HD WASHER 5/16      |


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## DRIVE

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22





| KEY NO. | PART NO.     | DESCRIPTION                   |
|---------|--------------|-------------------------------|
| 1       | 532 40 49-23 | (assy of 1a,1b) AXLE ASSEMBLY |
| 1a      | 532 40 43-07 | AXLE SHAFT                    |
| 1b      | 532 18 42-06 | ROLL PIN 3/16                 |
| 2       | 532 18 00-81 | GEAR                          |
| 3       | 532 17 46-97 | THRUST WASHER                 |
| 4       | 532 17 98-30 | AXLE BEARING                  |
| 5       | 532 14 63-15 | SCREW 5/16-18 X .625          |
| 6       | 817 49 05-08 | BOLT 5/16-18 X .500           |
| 7       | 532 15 54-43 | CLIK PIN                      |
| 8       | 532 18 92-82 | SQUARE KEY                    |


REPAIR PARTS

CHASSIS / PULLEYS

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| --      | -----        | B&S ENGINE MODEL 21M214-0920-E1 |
| 1       | 532 41 55-21 | FRAME                           |
| 2       | 532 41 08-77 | BOTTOM PAN                      |
| 3       | 532 42 38-73 | ENGINE MOUNT PLATE              |
| 4       | 532 15 04-06 | BOLT 3/8-16                     |
| 5       | 532 42 88-67 | SCREW 5/16-18 X .750            |
| 6       | 532 18 44-71 | SCREW 10-24 X .625              |




| KEY NO. | PART NO.     | DESCRIPTION    |
|---------|--------------|----------------|
| 1       | 532 40 91-61 | COVER ASSEMBLY |
| 2       | 532 17 88-13 | PULLEY         |
| 3       | 532 41 97-44 | TRACTION BELT  |
| 4       | 532 40 80-19 | IMPELLER BELT  |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.


REPAIR PARTS

WHEELS


SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



| KEY NO. | PART NO.     | DESCRIPTION          |
|---------|--------------|----------------------|
| 1       | 532 19 95-01 | WHEEL 16 X 4.80 X LH |
| 2       | 532 19 95-02 | WHEEL 16 X 4.80 X RH |



| KEY NO. | PART NO.     | DESCRIPTION        |
|---------|--------------|--------------------|
| 1       | 532 18 83-03 | STEER CABLE        |
| 2       | 874 04 10-24 | SCREW 10-24 X 1.50 |




| KEY NO. | PART NO.     | DESCRIPTION            |
|---------|--------------|------------------------|
| 1       | 532 41 52-63 | STEER CABLE BRACKET LH |
| 2       | 532 18 78-59 | STEER CABLE BRACKET RH |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## WHEELS

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



| KEY NO. | PART NO.     | DESCRIPTION         |
|---------|--------------|---------------------|
| 1       | 532 40 51-61 | COVER               |
| 2       | 532 18 44-71 | SHOULDER SCREW      |
| 3       | 812 00 00-45 | RETAINER RING       |
| 4       | 532 19 21-26 | WHEEL DRIVER        |
| 5       | 532 18 24-66 | RETAINER RING       |
| 6       | 532 18 76-22 | WHEEL LOBE          |
| 7       | 532 19 49-41 | CLUTCH SLIDE        |
| 8       | 532 17 91-39 | SPRING              |
| 9       | 532 18 92-82 | SQUARE KEY          |
| 10      | 532 19 49-40 | AXLE LOBE           |
| 11      | 532 17 46-97 | THRUST WASHER       |
| 12      | 532 19 95-19 | STEERING YOKE       |
| 13      | 532 18 41-97 | STEERING BRACKET    |
| 14      | 817 49 05-08 | SCREW 5/16-18 X .50 |
| 15      | 532 19 95-11 | PIVOT BRACKET       |
| 16      | 532 19 95-18 | BELLCRANK           |
| 17      | 532 18 18-47 | BELLCRANK PIN       |
| 18      | 817 60 04-06 | SCREW 1/4-20 X .375 |
| 19      | 532 40 50-77 | STEERING LINK       |
| 20      | 532 70 02-79 | RETAINER            |
| 21      | 532 08 51-79 | RETAINER            |
| 22      | 532 19 38-85 | SPRING              |
| 23      | 532 18 20-15 | LEVER PIN           |
| 24      | 532 19 95-12 | PIVOT BRACKET       |


**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.

REPAIR PARTS

BAG OF PARTS

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



| KEY NO. | PART NO.     | DESCRIPTION                 |
|---------|--------------|-----------------------------|
| 1       | 532 16 96-75 | RETAINER PIN                |
| 2       | 532 18 06-84 | WRENCH                      |
| 3       | 532 18 45-05 | REMOTE SPRING               |
| 4       | 532 17 98-29 | SHOULDER BOLT 1/4-20        |
| 5       | 532 19 17-30 | LOCKNUT 1/4-20              |
| 6       | 872 25 05-05 | CARRIAGE BOLT 5/16-18 X 5/8 |
| 7       | 532 75 11-53 | LOCKNUT 5/16-18             |
| 8       | 873 80 06-00 | LOCKNUT 3/8-16              |
| 9       | 819 13 13-16 | WASHER 3/8                  |
| 10      | 532 19 20-90 | SHEAR BOLT 1/4-20 X 1-3/4   |
| 11      | 873 80 04-00 | LOCKNUT 1/4-20              |

01.14.005-C

| KEY NO. | PART NO.     | DESCRIPTION         |
|---------|--------------|---------------------|
| 1       | 532 19 30-71 | SAFETY IGNITION KEY |




01.14.007-A

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm  
**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts.  
Failure to do so could be hazardous, damage your snow thrower and void your warranty.

## REPAIR PARTS

## DECALS

SNOW THROWER - MODEL NO. **ST2111E** (96191002204), PRODUCT NO. 961 91 00-22



| KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|---------------------------------|
| 1       | 532 19 96-83 | DECAL, DANGER                   |
| 2       | 532 40 58-08 | DECAL, JONSERED                 |
| 3       | 532 19 96-82 | DECAL, DANGER, DEFLECTOR        |
| 4       | 532 18 40-45 | DECAL, DANGER                   |
| 5       | 532 40 58-05 | DECAL, JONSERED, ST2111E        |
| 6       | 532 18 40-30 | DECAL, INSTRUCTION              |
| 9       | 532 41 54-77 | DECAL, SPEED CONTROL            |
| 10      | 532 18 40-31 | DECAL, REMOTE DEFLECTOR         |
| 11      | 532 41 54-59 | DECAL, TRIGGER, LH              |
| 12      | 532 41 54-60 | DECAL, TRIGGER, RH              |
| 13      | 532 18 04-33 | DECAL, NOISE LEVEL              |
| 14      | 532 18 40-28 | DECAL, BELT GUARD               |
| --      | 532 40 60-35 | OPERATOR'S MANUAL, EUROPEAN     |
| --      | 532 40 60-37 | OPERATOR'S MANUAL, SCANDINAVIAN |
| --      | 532 40 60-33 | OPERATOR'S MANUAL, EAST BLOC    |
| --      | 532 41 45-68 | OPERATOR'S MANUAL, BALTIC       |

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

**IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your snow thrower and void your warranty.